



Slow Juicer

Model Number CPJ1502

INSTRUCTION MANUAL

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au







Warranty Details

Slow Juicer

The product is guaranteed to be free from defects in workmanship and parts for a period of 36 months (dependant on product) from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Supplier name: Winplus Australasia
Supplier address: PO Box 537
Bayswater Business Centre VIC 3153
Supplier telephone: 1300 663 907
Supplier email address: customercare@winplus.com.au

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au





Contents

- 03 Warranty Page**
- 05 Welcome**
- 06 General Information and Safety Instructions**
- 07 Warnings**
- 09 Features & Technical Specifications**
- 10 Assembly and Parts List**
- 12 Instructions**
- 23 FAQ**
- 24 Other Useful Information**
- 25 Index**
- 26 Repair and Refurbished Goods or Parts Notice**

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Welcome

Congratulations on choosing to buy a Kuchef® product.

All products brought to you by Kuchef® are manufactured to the highest standards of performance and safety, and, as part of our philosophy of customer service and satisfaction, are backed by our comprehensive 3 Year Warranty.

We hope that you will enjoy using your purchase for many years to come.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



General Information and Safety Instructions

General Safety Instructions

- Keep Slow Juicer motor away from wet environments; only clean the base using a moist cloth.
- Keep away from heat sources such as heaters and ovens.
- If the Slow Juicer is not to be used for long periods of time, turn off and unplug from any power source.
- Do not use in dusty conditions.
- Do not drop or jar the Slow Juicer. Dropping or rough use of the unit will cause damage.
- Do not place near strong magnets or strong electric currents.
- Do not attempt repair open or alter any components of the Slow Juicer. In the case of improper usage or if you have opened, altered and repaired the product yourself, all guarantees are void.
- The supplier does not accept responsibility for additional or consequential damage other than covered by legal product responsibility.
- The supplier is not responsible for the end use of this product including any improper use or when used for purposes that are not specified.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au

Warnings

1. Read all instructions before operating the Slow Juicer for the first time.
2. This appliance is intended for household use only.
3. Do not use the appliance for other than intended or specified purposes.
4. Ensure the voltage specified on the appliances corresponds to the voltage in your home before plugging in the power cord. Incorrect voltage can cause damage or injury.
5. To avoid electrical shock, do not place the cord, plug or base unit in water or other liquids.
6. Do not operate appliance with wet hands or operate in a wet working environment.
7. Do not let the power cord hang off the edge of the table or counter or come in contact with hot surfaces.
8. If the power cord is damaged, it must be replaced by the manufacturer or a qualified repairer. See page 26 for contact details.
9. Unplug appliance from outlet when not in use.
10. This appliance is not intended for use by persons (including children) with reduced abilities without supervision.
11. Do not let children play with or operate the appliance under any circumstance.
12. Check strainer every time before use. In the event of any cracks or damage, contact the manufacturer. See page 26 for contact details.
13. Ensure all parts are securely locked while the appliance in use. Do not operate or open the appliance while in operation.
14. Avoid contact with moving parts. When disassembling ensure the appliance is unplugged from the power socket.
15. Do not place the appliance on or near a hot surface.
16. Always supervise the appliance while in use.
17. Do not disassemble the base or access the motor housing.
18. Do not use the appliance for more than 30 minutes continuously.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



- 19.** Do not force food material through the auger. If food material prevents auger rotation, stop the appliance immediately to avoid damage. Unplug the appliance, open the lid to remove the obstruction before resuming operation.
- 20.** If clogging occurs, immediately cease operation of the motor. Reverse the motor to release the blockage. Unplug the power cord and clear the block before resuming operation.
- 21.** Only use the provided plunger to gently feed food into the feed chute. Do not place your hands or fingers inside the slow juicer while in operation.
- 22.** Ensure all ingredients are cut into small pieces and remove the core before juicing or it may cause clogging.
- 23.** If you experience any abnormal sound, smell or overheating. Immediately cease operation and unplug the power cord. Contact the manufacturer for assistance. See page 26 for contact details.
- 24.** Hard ingredients such as carrots should not exceed 15mm width.
- 25.** Fibrous ingredients such as celery should not exceed length of 5cm to avoid blocking the waste extraction chute.
- 26.** Ensure efficient time between ingredients being fed into the juicer to prevent blockage. This will vary depending on the ingredient.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Features

- Low speed squeezing system
- Low noise operation
- Quick and easy self-cleaning
- Continuous extraction system
- Includes frozen fruit maker attachment to make delicious frozen desserts
- Overload protection

Technical Specifications

Model Number: CPJ1502

Speed: 80RPM

Colour: Stainless Steel

Weight: 3.8kg

Voltage: 220-240VAC 50HZ

Dimensions: 385x255x360mm

Power: 150W

Warranty: 3 years.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Assembly and Parts List



After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au

Assembly and Parts List



- | | | | |
|----|------------------------|-----|---------------------------|
| 1. | Plunger | 7. | Auger |
| 2. | Lid | 8. | Juice Strainer |
| 3. | Feed Chute | 9. | Rotating Basket |
| 4. | On /Off Switch | 10. | Bowl |
| 5. | Waste Extraction Chute | 11. | Frozen Dessert Attachment |
| 6. | Juice Spout | | |

After Sales Support

Telephone: 1300 663 907
Email: customer-care@winplus.com.au

Assembly Instructions

Note: Before first use, disassemble the Slow Juicer and wash all removable parts in warm water with a bio-degradable non-abrasive liquid detergent. Rinse thoroughly with water and allow to air dry.

Warning: Never submerge the Slow Juicer base in water or any other liquid.

Note: The Slow Juicer must be assembled in the following order:

- a. Bowl
- b. Rotating basket
- c. Strainer
- d. Auger
- e. Food chute



- 1.** Place the bowl on the base using the safety lock symbol as a guide. Twist the bowl gently clockwise to lock the bowl firmly to the base.



- 2.** Assemble the rotating basket then the strainer inside the bowl. Ensure the red dot on the rotating basket lines up with the red dot on the bowl.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



- 3.** Place the auger inside the centre of the strainer. Press the auger down gently to ensure a proper fit.



- 4.** Place the lid on top of the bowl and rotate to lock into place. Ensure the locking symbols align on the lid.



- 5.** Place the pulp container under the pulp remover spout and the juice jug under the juice spout.



- 6.** Ensure all parts are securely in place before use.

Note: To disassemble the Slow Juicer simply follow these instructions in reverse order.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au

Getting Started

How to: Juice

1. Once you have securely fastened all parts in place, connect the power cord to a power outlet and switch on the outlet.
2. Prepare your ingredients for use, make sure you have washed all the ingredients thoroughly and cut to an appropriate size to fit easily into the food chute. Remove any hard seeds before juicing.
3. Your slow juicer has 3 motor settings.



- ON – Used to juice the ingredients.
- OFF – Turns the motor off.
- REVERSE – Will reverse the auger direction. Can be used to dislodge any clogged or blocked ingredients. You must hold down the switch during reverse operation.

5. Operate the Slow Juicer by pressing the switch to the ON position.

Tips: If the juicer won't start, check the following:

- Juicer is plugged in, and power outlet is turned on.
- Lid is securely locked into place. Note the alignment of the locking symbol.

6. Slowly feed your ingredients into the food chute. Generally the auger will pull most ingredients and begin juicing.
7. The juice will begin to flow out of the juice spout almost immediately and any pulp will exit through the waste extraction chute.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Warning: Never force any ingredients. Never use any ingredients larger than specified in this manual.

Tip: You can switch ingredients at any time and use the easy clean system to keep juicing without disassembling the unit. Simply pour warm water through the food chute to help clean out any pulp or residue.

Note: This is not an alternative to a complete cleaning of each part after disassembly. Ensure you thoroughly clean the unit after each use.

How to: *Mix*

The Slow Juicer not only creates tasty and healthy juices, you can also mix together your favourite juices without the need for a blender.

1. Once you have securely fastened all parts in place, connect the power cord to a power outlet and switch on the outlet.
2. Prepare your ingredients for use, make sure you have washed all the ingredients thoroughly and cut to an appropriate size to fit easily into the food chute. Remove any hard seeds before juicing.
3. Place the juice jug underneath the spout. Ensure the juice spout is closed.
4. Pour the ingredients into the food chute. The auger will crush the ingredients while the rotating basket mixes the juice together.
5. Once the juice has been mixed together. Switch off the juicer and carefully lift the juice spout cover. Ensure you have the juice jug in place to catch the juice.
6. You can now enjoy your freshly made juice.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



How to: *Make Frozen Fruit Desserts*

The Slow Juicer comes with a frozen fruit dessert maker to make delicious and healthy frozen fruit desserts.

1. Prepare your ingredients for use, removing the peels, skins, stems and hard seeds from any fruit you wish to use. Cut into manageable pieces before freezing.
2. Place fruit in the freezer overnight.

Tip: It is recommended that you thaw the fruit pieces at room temperature for 8-10mins before use.

3. Assemble Slow Juicer using the frozen dessert attachment in place of juice strainer and rotating basket. Insert the auger inside the frozen fruit dessert attachment as shown.



Note: You do not need to insert the rotating basket when using the frozen dessert maker.

4. Place the pulp catcher under the waste extraction chute and close the juice spout cover.
5. Feed frozen fruits through the food chute. The frozen dessert will be fed through the auger and exit the juicer from the waste chute.

How to: *Clean*

To prolong the life of your Slow Juicer and to ensure the best tasting juices, you should thoroughly clean the unit and all components after each use.

1. Switch off the unit and disconnect from the power outlet.
2. Turn the lid in an anti-clockwise direction to unlock.
3. Remove the auger, strainer and rotating basket.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Note: If the auger is difficult to remove, replace the lid and operate in reverse for about 3 seconds then start over again from step 1 .

4. Turn the bowl in an anti-clockwise direction to unlock then gently lift off the bowl from the base.
5. Disassemble the components in the following order.
 - a. Food chute
 - b. Auger
 - c. Strainer
 - d. Rotating basket
 - e. Bowl
6. Using the included cleaning brush, thoroughly clean each of the components in warm soapy water.

7. Fibrous material can build up in the waste extraction chute. To clear the blockage, remove the silica pad as shown. Use the cleaning brush to assist.



8. Do not use abrasive clothes or liquids to clean. Do not wash the Slow Juicer base. You can clean this using a moist cloth.
9. Air dry all components before you re-assemble the unit.

Tip: Use the cleaning brush hook to get rid of any hard to remove residue or pulp from the waste extraction chute.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Recipes & Tips.

All recipes should be made using fresh chilled ingredients. The juices can be frozen and used at a later date but are best consumed fresh. Ensure you wash all ingredients before use.

Classic Juices

Orange Juice

- Peel oranges and cut into quarters.
- Feed into the food chute at a steady pace.

Tip: Combine different kinds of citrus fruits together to make your own juice combination.

Carrot Juice

- Slice carrots into 8cm lengths, around 1.5cm wide.
- Feed into the food chute at a steady pace. Do not force the carrot sticks into the juicer.

Tip: Use carrot juice as a base for your own juice combinations. There is no need to peel the carrots, the carrot peel contains many antioxidants, vitamins and minerals.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Celery Juice

- Cut stalks into 2-3cm lengths. Longer fibres can clog the waste chute.
- Feed into the food chute at a steady pace, do not force the celery sticks into the juicer.

Tip: Rinse the juicer out between each bunch of celery by pouring a cup of water through the system. This will help prevent build up of fibrous pulp.

Apple Juice

- Cut the apple into quarters or eighths depending on the size of the apple.
- De-core the apple as the seeds may get stuck in the juicer.
- There is no need to peel the apples.
- Feed into the juicer at a steady pace.

Tip: Use 5-6 apples and 1 cup of strawberries to create a delicious drink.

Favourite Combination Juices

Green Pineapple Juice

- 1 cups of fresh chunked pineapple.
- 1 large green apple. Remove the core and cut into quarters or eighths.
- ½ a lemon, with or without zest.
- 8-10 mint leaves.

Feed all ingredients into the juicer. Keep the juice spout lid closed to mix the ingredients together.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Pink Passion

- 1 cup of watermelon
- ½ grapefruit
- 1 pink lady apple

Peel the grapefruit and watermelon, and cut into manageable pieces.

Core the apple and cut into quarters or eighths.

Feed all ingredients into the juicer. Keep the juice spout lid closed to mix the ingredients together.

Tip: For a sweeter drink, substitute the pink grapefruit for blood orange.

Citrus Blast

- 2 blood oranges
- 1 mandarin
- 1 yellow grapefruit

Peel and cut the citrus fruits into quarters or eighths.

Feed all ingredients into the juicer. Keep the juice spout lid closed to mix the ingredients together.

Tip: Swap the grapefruit for some lemon or lime to add some variety to the recipe.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Very Berry Combo

- 1 punnet strawberries
- 1 punnet blueberries
- ½ cup raspberries
- 1 green apple. Remove the core and cut into quarters or eighths

Feed all ingredients into the juicer. Keep the juice spout lid closed to mix the ingredients together.

Tip: To spice up any of the recipes above, try one of the following additions:

- Fresh Ginger
- Cinnamon
- Nutmeg
- Celery Seed
- Ground Cumin
- Hot Pepper Sauce
- Fresh Ground Pepper

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Frozen Fruit Desserts

Many recipes use bananas as the basis for a smooth, creamy dessert. It is also possible to make delicious sorbets with some of your favourite fruits.

Banana and Honey Dessert

- 2 medium bananas; peeled and frozen
- 1 tbsp honey

Let fruit thaw for 8-10 minutes at room temperature. Insert banana. Mix together with the honey and serve.

Berry and Chocolate Dessert

- 1 medium banana; peeled and frozen
- 1/2 cup frozen mixed berries
- 20g dark chocolate

Let fruit thaw for 8-10 minutes at room temperature. Insert banana, chocolate and berries. Mix together and serve.

Mango Sorbet

- 1 cup of mango peeled and frozen with seeds removed

Let fruit thaw for 8-10 minutes at room temperature. Insert mango and serve.

Tip: You can add frozen berries to this dessert for a new flavour.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au

FAQ

Problem	Solution
<i>My juicer won't turn on</i>	<ul style="list-style-type: none">• Check the power outlet is turned on• Check that the lid is correctly locked into position
<i>The auger will not turn</i>	<ul style="list-style-type: none">• Check the power outlet is turned on.• Check there are no blockages, turn off at the power outlet before disassembly.• Turn the machine off, switch to reverse for 3 seconds. This may clear a blockage.
<i>There is a blockage</i>	<ul style="list-style-type: none">• Turn the machine off, switch to reverse for 3 seconds. This may clear a blockage.• Unplug the power cord, remove any large food chunks inside the auger. Connect to power again and switch to on.
<i>The auger is getting stuck when i try to juice certain ingredients</i>	<ul style="list-style-type: none">• Ensure you have cut the ingredients into manageable sizes Recommended size is 8cm long and 1.5cm wide. It is recommended for fibrous ingredients such as celery or hard ingredients such as carrots to cut in smaller sizes around 3cm lengths.
<i>The plastic juice jug or mixing jug is stained</i>	<p>Carotenoids that are present in many vegetables, but especially carrots, can stain the plastic components of the juicer. We suggest any 1 of the following cleaning tips to help remove any stains.</p> <ul style="list-style-type: none">• Biodegradable soap in warm water• 1 part warm water, 1 part cider vinegar• Baking soda and warm water
<i>Can't remove the auger</i>	<p>If you can't pull out the auger, reassemble the lid, turn juicer on and operate in reverse for a few seconds then try again.</p>
<i>Lid won't fit</i>	<ul style="list-style-type: none">• Ensure the parts are assembled correctly in place• Check the silica pad has been pushed into its slot• Make sure the auger is pushed all the way down

Tip: Cleaning the components immediately after use will assist in reducing any stains occurring.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Other Useful Information

Spare Parts Notice

Spare parts for the Kuchef Slow Juicer are available including:

- Brushes
- Foot pads
- Silica pads
- Pulp jugs
- Juice jugs
- Rotating baskets
- Juice filters
- Frozen dessert makers

To enquire about spare parts availability:

Please contact Winplus after sales support.

Telephone: 1300 663 907

Email: customercare@winplus.com.au

Warranty Details

For details, see page 3.

Repair & Refurbished Goods or Parts Notice

For details, see page 26.

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au

Index

Assembly and Parts List	10
Assembly Instructions	12
Auger	8, 10, 12, 13, 14, 15, 16, 17, 23
Bowl	10, 12, 13, 17
Classic Juices	18
Cleaning Brush	17, 24
Combination Juices	19
Contents	4
FAQ	23
Features	9
Frozen Dessert Attachment	10, 24
Frozen Fruit Dessert Recipes	22
General Safety	6
Getting Started	14
How to Clean	16
How to Juice	14
How to Mix	15
How to use Frozen Fruit attachment	16
Juice Jug	13, 15, 23
Juice Strainer	10, 16
Lid	8, 10, 13, 14, 16, 17, 19, 20, 21, 23
Other Useful Information	24
Plunger	8, 10, 11
Pulp Container	13
Recipes	18
Rotating Basket	10, 12, 15, 16, 17
Silica Pad	17
Technical Specifications	9
Warnings	7-8
Warranty Details	3
Welcome	5

After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



Repair & Refurbished Goods or Parts Notice

Slow Juicer

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost.

We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on SUPPLIER TELEPHONE or write to us at:

Supplier name: Winplus Australasia
Supplier address: PO Box 537
 Bayswater Business Centre VIC 3153
Supplier telephone: 1300 663 907
Supplier email address: customercare@winplus.com.au

After Sales Support
 Telephone: 1300 663 907
 Email: customercare@winplus.com.au





After Sales Support

Telephone: 1300 663 907
Email: customercare@winplus.com.au



