


BAUHN®

Version 1.2

## SAFETY WARNINGS

- Only use attachments/accessories specified by the manufacturer
- To avoid accidental ingestion, keep the earbuds away from children and pets
- The earbuds contain a lithium-ion battery, and may be hazardous if swallowed
- If ingested, seek immediate medical attention
- When not in use, store the earbuds in the charging case with the lid closed, and keep out of reach of children and pets
- Do NOT use the earbuds at a high volume for any extended period
- To avoid hearing damage, use your earbuds at a comfortable, moderate volume level
- Turn the volume down on your device before placing the earbuds in/on your ears, then turn the volume up gradually until you reach a comfortable listening level
- Use caution and follow applicable laws regarding mobile phone and headphone use if using the earbuds for phone calls while driving
- Some jurisdictions impose specific limitations, such as single earpiece configuration, on the use of such products while driving
- DON'T use the earbuds for any other purpose while driving
- Focus on your safety and that of others if you use the earbuds while engaging in any activity requiring your attention, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad and follow applicable laws regarding headphone use, etc.
- Remove the earbuds or adjust your volume to ensure you can hear surrounding sounds, including alarms and warning signals
- Do NOT allow children to use the earbuds. Contains small parts which may be a choking hazard
- Do NOT submerge or expose the earbuds for extended period to water, or wear while participating in water sports, e.g., swimming, water-skiing, surfing, etc
- To reduce the risk of injury, close supervision is necessary when the charging case is used near children
- Do not expose charging case to water, rain, liquids or snow
- Do not use the charging case in excess of its output rating
- Do not use a charging case that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury to persons
- Do not disassemble the charging case. Incorrect reassembly may result in risk of fire or injury to persons
- Do not open, crush, or expose a charging case to fire, or excessive temperature. Exposure to fire or temperature above 45°C may cause explosion
- Have servicing performed by a qualified repair person using only identical replacement parts
- Do NOT make unauthorized alterations to this product
- Use this product only with an agency approved power supply which meets local regulatory requirements (e.g., CE)
- Wipe off sweat from the earbuds and the charging case before charging
- This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device
- Excessive sound pressure from earphones and headphone can cause hearing loss
- Attention should be drawn to the environmental aspects of battery disposal
- Use only with charger base provided with the earbuds
- Use of apparatus in moderate climates
- This product shall not be connected to power supply source exceeding PS1. 5V d.c. 15W.



# WIRELESS SPORTS EARBUDS

USER GUIDE

CE220784  
01/25

### CAUTION: Risk of explosion:

- If the battery is replaced by an incorrect type.
- If the battery is subjected to high or low extreme temperatures that a battery can be subjected to during use, storage or transportation.
- If the battery is subjected to low air pressure at high altitude.
- Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types).
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.



BAUHN®

WIRELESS SPORTS EARBUDS

## Warranty Details

REGISTER YOUR PURCHASE AT [www.aldi.com.au/en/about-aldi/product-registration/](http://www.aldi.com.au/en/about-aldi/product-registration/) TO KEEP UP-TO-DATE WITH IMPORTANT PRODUCT INFORMATION

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

AFTER SALES SUPPORT

1300 663 907

customercare@balcobrands.com

MODEL: CE220784 PRODUCT CODE: 718492 01/2025



## IN THE BOX

1. Wireless sports earbuds
2. Earbud charging case
3. 3 X Silicone earbud tips pairs - (s,m,l)
4. USB C charging cable
5. User guide\*
6. Warranty card\*

\*Not pictured




## FUNCTIONS

- a. Touch control area
- b. LED indicator light
- c. Microphone (internal)\*
- d. Charging case charging port
- e. Charging case indicator lights

\*Not pictured

Note: Product rating label is on the bottom of charging case



Front of case

Back of case

## CHARGING

### Charging case

1. Connect the USB C end of the supplied USB C charging cable into the charging case charging port
2. Connect the USB end of the charging cable into PC or AC/DC wall adaptor (not provided)

While charging the charging case, 4 white LED lights will display the battery status of the charging case

- Battery is 100% charged, all 4 white lights will remain solid
- Battery is 75% charged, three LED lights will be white, and the fourth LED will flicker white
- Battery is 50% charged, two LED lights will be white, and the third LED will flicker white
- Battery is 25% charged, one LED light will be white, and the second LED will flicker white
- Battery is less than 25% charged, the first LED will flicker white

### Earbuds

The earbuds will start charging when put back into the charging case. A red LED will be displayed if the earbuds are charging, once fully charged this light will turn off.

## TURNING ON/OFF

### Turning on

The earbuds will automatically turn on when removed from the charging case. To manually power the earbuds on hold the touch surface for 5 seconds and you will receive a prompt

### Turning off

The earbuds will automatically turn off when placed in the charging case.

## PAIRING

1. Place both earbuds into the charging case to activate the earbuds
2. Take both earbuds out from the charging case, they will power on and connect with each other automatically
3. The LED will flicker Red/Blue to indicate that the earbuds are now in pairing mode
4. Enable Bluetooth on your device and select "CE220784" from the list to connect
5. Your device will show if it is connected successfully

**NOTE:** The earbuds will automatically connect to your last previously connected device. To connect to a new device first disconnect the earbuds from the currently paired device.

## TOUCH CONTROL AREA

You can control a variety of different functions on your mobile device using the touch control area on your earbuds

Play/Pause Music	Short press either the left or right earbud
Next Track	Long press right earphone 2 seconds
Previous Track	Long press left earphone 2 seconds
Answer Call	With a call incoming short press either the left or right earbud
End Call	During a call short press either the left or right earbud
Reject Incoming Call	With a call incoming long press either the left or right earbud
Activate Voice Assistant	Double click either left earphone or right earphone to turn on voice assistant

## TECH SPECS

Driver Unit:	8mm
Impedance:	32Ω
Bluetooth Version:	5.4
Transmission Range:	Up to 10 metres
Earbuds Playback Time:	Up to 5 hours
Total Playback Time With Charging Case:	Up to 15 hours
Charging Case Battery:	400mAh Lithium Battery
Earbuds Battery:	40mAh
Power Input:	DC 5V 500mA
Earbuds Water Resistant: (Not including charging case)	IPX5

## AFTER SALES SUPPORT

If you experience any issues with this product or its performance is not what you had expected, please contact us at Balco Brands

It is likely that we can resolve any problems for you via phone or email

We can be reached on:

Phone: 1300 663 907 (Mon - Fri; 8:30am - 6:00pm AEST)  
Email: [customercare@balcobrands.com](mailto:customercare@balcobrands.com)  
Web: [www.balcobrands.com](http://www.balcobrands.com)



**BAUHN®**

**WIRELESS SPORTS EARBUDS**

## Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost.

**We recommend you save this data elsewhere prior to sending the product for repair.**

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

**Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.**

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 663 907 or write to us at:

Balco Brands Pty Ltd

PO Box 537 Bayswater Business Centre, Victoria, Australia

1300 663 907 - Hours: Mon-Fri 8:30am - 6:00pm AEST

[customercare@balcobrands.com](mailto:customercare@balcobrands.com)

### AFTER SALES SUPPORT

1300 663 907

[customercare@balcobrands.com](mailto:customercare@balcobrands.com)

MODEL: CE220784 PRODUCT CODE: 718492 01/2025

**1**

YEAR WARRANTY