

SOLAR POWERED
SPEAKER

USER GUIDE

CE220819
07/2025

SAFETY WARNINGS

- Do not disassemble or throw into fire or water, to avoid damage
- Keep this product in a dry place. Never place or use the product in wet or dirty conditions
- Do not squeeze or puncture the Solar Powered Speaker to avoid electrolyte leakage of lithium-ion battery
- Handle with care. Avoid dropping this device, especially on a hard surface. Do not crush, bend, deform, puncture, shred or submerge this device in liquid
- Do not use Solar Powered Speaker in severely hot, humid or corrosive environments, to avoid circuit damage and leakage
- Do not place too close to magnetic strips or chip cards (ID card, credit cards, etc.) to avoid magnetic failure
- Please keep a distance of at least 30cm between implantable medical devices (pacemakers, implantable cochlear, etc.) and the Solar Powered Speaker, to avoid potential interference with the medical device
- Ensure children do not play with the Solar Powered Speaker. This is not a toy
- Do not use damaged power cords, plugs or loose electrical sockets
- Only use original cable and reputable third-party chargers
- Do not use a damaged cable or power charger to charge the Solar Powered Speaker
- Use only an adaptor with output of 5.0V DC to charge the Solar Powered Speaker. Incorrect voltage may cause damage to the product or associated accessories
- Do not clean the Solar Powered Speaker with harmful chemicals or detergents
- Misuse, dropping or excessive force may cause damage to the charging pad
- Do not touch the device, power cords, plugs, or the electric socket with wet hands or other wet body parts
- After charging your device, please remove the charging cable to avoid unnecessary consumption of the battery
- Never use the Solar Powered Speaker if any part of it is damaged
- Attention should be drawn to the environmental aspects of battery disposal
- Use of apparatus in moderate climates

CAUTION: Risk of explosion:

- If the battery is replaced by an incorrect type.
- If the battery is subjected to high or low extreme temperatures that a battery can be subjected to during use, storage or transportation.
- If the battery is subjected to low air pressure at high altitude.
- Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types).
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- This product shall not be connected to power supply source exceeding PS1. 5V d.c. 15W.



BAUHN®

SOLAR POWERED SPEAKER

Warranty Details

REGISTER YOUR PURCHASE AT www.aldi.com.au/en/about-aldi/product-registration/ TO KEEP UP-TO-DATE WITH IMPORTANT PRODUCT INFORMATION

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

AFTER SALES SUPPORT

1300 663 907

customercare@balcobrands.com


MODEL: CE220819 PRODUCT CODE: 720137 07/2025



IN THE BOX


1. Solar powered speaker
2. USB charging cable
3. User guide*
4. Warranty card*

*Not pictured



FUNCTIONS

1. Solar panel (on top)
2. Microphone
3. Solar charging LED indicator
4. Bluetooth/charging LED indicator
5. Volume + button
6. Mode Button
7. Next track button
8. Volume - button
9. Charging port
10. Previous track button



CHARGING THE SPEAKER

Cable

1. Connect the provided charging cable to a power source and to the Type-C input port ⑨ on the speaker.
2. The LED indicator ④ will glow RED when charging, and will turn OFF when fully charged.
3. When the speaker is low on power, a tone will be heard indicating that it needs to be recharged

NOTE:

- Charge only with 5V DC output USB port
- Use only the original USB-C charging cable to avoid any damage
- Remember to turn off the power supply before removing the charging cable
- Be sure to fully charge the speaker before using for the first time

Solar power

1. Place the speaker in a sunny location with the solar panel facing bright/consistent sunlight. The speaker will begin to charge automatically.
2. The solar charging LED indicator ③ will turn RED while charging and turn OFF when fully charged.

PAIRING THE SPEAKER

1. Press and hold the mode button ⑥ to turn ON the speaker, the Bluetooth LED indicator ④ will flash BLUE and speaker will tone when in bluetooth standby mode.
2. Turn on the Bluetooth function of the mobile device, select the “CE220819” pairing name.
3. Speaker will tone and LED indicator will glow BLUE if successfully paired and will flash in BLUE slowly when playing.
4. Speaker will automatically pair if the mobile device has been paired before.
5. Press and hold the mode button ⑥ to turn OFF the speaker
6. If the speaker isn't connected to Bluetooth it will automatically power off after 5 minutes.

QUICK CONTROLS

You can control a variety of different functions by using the control buttons on the back of the speaker

Increase Volume	Short press + button
Decrease Volume	Short press - button
Pause	Short press ▶ button
Play	Short press ▶ button
Previous track	Short press ◀ button
Next Track	Short press ▶ button
Answer/End call	Short press the ▶ button
Reject call	Long press the ▶ button

TECH SPECS

Battery: 3.7V , 1500mAh, 5.55Wh
Bluetooth Version: 5.4
Power Input: 5V = 500mA
Water resistant: IPX5

AFTER SALES SUPPORT

If you experience any issues with this product or its performance is not what you had expected, please contact us at Balco Brands

It is likely that we can resolve any problems for you via phone or email

We can be reached on:

Phone: 1300 663 907 (Mon - Fri; 8:30am - 6:00pm AEST)
Email: customercare@balcobrands.com
Web: www.balcobrands.com



BAUHN®

SOLAR POWERED SPEAKER

Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost.

We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 663 907 or write to us at:

Balco Brands Pty Ltd

PO Box 537 Bayswater Business Centre, Victoria, Australia

1300 663 907 - Hours: Mon-Fri 8:30am - 6:00pm AEST

customercare@balcobrands.com

AFTER SALES SUPPORT

1300 663 907

customercare@balcobrands.com

MODEL: CE220819 PRODUCT CODE: 720137 07/2025

