

PREMIUM

WIRELESS EARBUDS



USER GUIDE

Version 1.3

CE220664
12/24

SAFETY WARNINGS

- Only use attachments/accessories specified by the manufacturer
 - To avoid accidental ingestion, keep the earbuds away from children and pets
 - The earbuds contain a lithium-ion battery, and may be hazardous if swallowed
 - If ingested, seek immediate medical attention
 - When not in use, store the earbuds in the charging case with the lid closed, and keep out of reach of children and pets
 - Do NOT use the earbuds at a high volume for any extended period
 - To avoid hearing damage, use your earbuds at a comfortable, moderate volume level
 - Turn the volume down on your device before placing the earbuds in/on your ears, then turn the volume up gradually until you reach a comfortable listening level
 - Use caution and follow applicable laws regarding mobile phone and headphone use if using the earbuds for phone calls while driving
 - Some jurisdictions impose specific limitations, such as single earpiece configuration, on the use of such products while driving
 - DON'T use the earbuds for any other purpose while driving
 - Focus on your safety and that of others if you use the earbuds while engaging in any activity requiring your attention, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad and follow applicable laws regarding headphone use, etc.
 - Remove the earbuds or adjust your volume to ensure you can hear surrounding sounds, including alarms and warning signals
 - Do NOT allow children to use the earbuds. Contains small parts which may be a choking hazard
 - Do NOT submerge or expose the earbuds for extended period to water, or wear while participating in water sports, e.g., swimming, water-skiing, surfing, etc
 - To reduce the risk of injury, close supervision is necessary when the charging case is used near children
 - Do not expose charging case to water, rain, liquids or snow
 - Do not use the charging case in excess of its output rating
 - Do not use a charging case that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury to persons
 - Do not disassemble the charging case. Incorrect reassembly may result in risk of fire or injury to persons
 - Do not open, crush, or expose a charging case to fire, or excessive temperature. Exposure to fire or temperature above 45°C may cause explosion
 - Have servicing performed by a qualified repair person using only identical replacement parts
 - Do NOT make unauthorized alterations to this product
 - Use this product only with an agency approved power supply which meets local regulatory requirements (e.g., CE)
 - Wipe off sweat from the earbuds and the charging case before charging
 - This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device
 - Excessive sound pressure from earphones and headphone can cause hearing loss
 - Attention should be drawn to the environmental aspects of battery disposal
 - Use only with charger base provided with the earbuds
 - Use of apparatus in moderate climates
 - This product shall not be connected to power supply source exceeding PS1. 5V d.c. 15W.
- CAUTION: Risk of explosion:**
- If the battery is replaced by an incorrect type.
 - If the battery is subjected to high or low extreme temperatures that a battery can be subjected to during use, storage or transportation.
 - If the battery is subjected to low air pressure at high altitude.
 - Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types).
 - Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
 - Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- Do not dispose of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Do not leave a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- Do not expose the battery to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.




- High sound pressure
- Hearing damage risk
- Do not listen at high volume levels for long periods

IN THE BOX

1. 1 x Premium Wireless Earbuds
2. 3 x Pairs Of Silicone Ear Tips (S, M, L)
3. 1 x Earbud Charging Case
4. 1 x USB C Charging Cable
5. 1 x User Guide*
6. 1 x Warranty Certificate*

*Not pictured


1




2



3





4



FUNCTIONS

- a. Touch control area
- b. Microphone
- c. LED indicator light
- d. Lanyard loop (lanyard not included)
- e. Earbud charging point
- f. Charging case charging port


Note: Product rating label is on the back of charging case



CHARGING

Charging case

1. Connect the USB C end of the supplied USB C charging cable into the charging case charging port
2. Connect the USB end of the charging cable into PC or AC/DC wall adaptor (not provided)



While charging the charging case, a blue LED light will display the battery status of the charging case

- Battery is 100% charged, LED light will be blue for 10 seconds
- Battery is 75% charged, three LED lights will be blue, and the fourth LED will flicker blue
- Battery is 50%, two LED lights will be blue and a third LED will flicker blue
- Battery is 25%, a LED light will be blue

Earbuds

The earbuds will start charging when put back into the charging case. A LED will flicker red for 3 seconds while charging. Once the earbuds are fully charged, the LED will pulse blue.

Note: The LED light will turn off after 60 seconds

TURNING ON/OFF

Turning on

Take both earbuds out from the charging case, they will turn on and connect with each other automatically. Alternatively press the multi function touch button for 5 seconds

Turning off

Put the earbuds back into the charging case and close completely, they will turn off automatically. Alternatively press the multi function touch button for 5 seconds

PAIRING


Method 1

1. Place both earbuds into the charging case to activate the earbuds
2. Take both earbuds out from the charging case, they will power on and connect with each other automatically
3. The LED will flicker Red/Blue to indicate that the earbuds are now in pairing mode
4. Enable Bluetooth on your device and select “CE220664” from the list to connect
5. Your device will show if it is connected successfully



Method 2 - Connection Reset


1. When the earbuds are turned off, touch them for 12 seconds until the LED turns red for 3 seconds. Turn off the earbuds and place them back into the charging case
2. Take both earbuds out from the charging case, they will power on and connect with each other automatically
3. Enable Bluetooth on your device and select “CE220664” from the list to connect
4. Your device will show if it is connected successfully



After the earbuds are connected via Bluetooth when you open the charging case the earbuds will connect to the last device it has been connected to. Only one device can be linked at any time, you must forget the earbuds from the first device to connect to a new device. If the connected Bluetooth device is not in range, the earbuds will go into searching mode which will last around 10 minutes. Sound quality and connectivity may vary depending on the device being used

TOUCH CONTROL AREA

You can control a variety of different functions on your mobile device using the touch control area on your earbuds



Play/Pause Music	Press and hold the right earbud touch control area for 2 seconds
Next Track	Double tap the touch control area on the right earbud
Previous Track	Double tap the touch control area on the left earbud
Volume Up	Press the touch control area on the right earbud once to increase the volume
Volume Down	Press the touch control area on the left earbud once to decrease the volume
Answer Call	Single tap the touch control area on either earbud

End Call	Press and hold the touch control area for 2 seconds on either earbud
Reject Incoming Call	Double tap the touch control area when a call is incoming
Activate Voice Assistant	Press and hold the left earbud touch control area for 2 seconds
Low Latency Mode	Triple tap the touch control area to turn on/off low latency mode

TECH SPECS

Bluetooth version:	V5.2
Wireless distance:	10m
Earbud battery:	3.7V 40mAh 0.148Wh
Charging case battery:	3.7V 300mAh 1.11Wh
Input rating:	5V  500mA
Operation frequency band:	2402MHz–2480 MHz
Maximum radio-frequency power transmitted:	less than 20dBm

Note: Product rating label is on the back of charging case

AFTER SALES SUPPORT

If you experience any issues with this product or its performance is not what you had expected, please contact us at Balco Brands

It is likely that we can resolve any problems for you via phone or email

Phone:  0800 496 9698
 1800 816994

Email: UK-IRE@balcobrands.com

 This product complies with EU WEEE Directive (2012/19/EU). This product bears a classification symbol for waste electrical and electronic equipment (WEEE). This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

 Packaging materials of the product are manufactured from recyclable materials in accordance with our National Environment Regulations. Do not dispose of the packaging materials together with the domestic or other wastes. Take them to the packaging material collection points designated by the local authorities.

 Hereby, Balco Brands declares that the radio equipment Premium Wireless Earbuds is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://balcobrands.com/download/CE220664-ECDOC.PDF>