



USER GUIDE

DUAL PORT WALL CHARGER



BAUHN

AFTER SALES SUPPORT

864595

GB



0800 496 9698

UK-IRE@BALCOBRANDS.COM

IE



1800 816 994

UK-IRE@BALCOBRANDS.COM

MODEL: CE220839-WAUK

12/2026

1 SAFETY INFORMATION

- Keep the product away from dirt, moisture, and overheating. Use only in dry indoor areas.
- Do not drop or expose the product to strong impacts.
- Operate the product only within the power limits specified in the technical data.
- Do not modify the product. Any modification will void the warranty.
- Stop using the product if it shows visible damage.
- Use the product only as intended.
- Keep the device out of reach of children.
- Do not use near heaters, other heat sources, or in direct sunlight.
- Keep away from flammable materials and avoid use in high-temperature conditions.
- Route cables to prevent tripping hazards.
- Do not bend, twist, or crush cables.
- Always unplug by pulling the plug, not the cable.
- Dispose of packaging materials according to local regulations.
- For indoor use only.
- Operate only under moderate climatic conditions.
- Do not use the device in restricted areas where electronic products are prohibited.
- Avoid damp environments and protect from splashing water.
- Use in a well-ventilated indoor environment. Avoid covering the charger or placing it on soft surfaces (e.g., beds or sofas) to prevent overheating.



RISK OF ELECTRIC SHOCK

- » Do not open the device or attempt to operate it if it is damaged.
- » Do not use the product if the adapter or cable is damaged.
- » Do not attempt to repair or service the product yourself.
- » All service work must be carried out by qualified professionals.
- » Disconnect the charger from the power source before cleaning or when not in use.



This product complies with EU WEEE Directive (2012/19/EU). This product bears a classification symbol for waste electrical and electronic equipment (WEEE).

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



This product fulfils the European directives 2011/65/EU and 2014/30/EU.



**PRODUCED IN
CHINA FOR**

ALDI STORES LTD.

PO Box 26,
ATHERSTONE,
WARWICKSHIRE,
CV9 2SH

**ALDI STORES (IRELAND)
LTD.**

PO Box 726,
NAAS,
CO. KILDARE

WWW.ALDI.CO.UK | WWW.ALDI.IE

MADE IN CHINA

**V1-1
12/2026**

2 CHARGING YOUR DEVICES

1. Connect your device to the USB-A or USB-C port using a suitable USB cable.
2. Plug the charger into a wall outlet.
3. The charging status will be displayed on your device.
4. Disconnect your device when fully charged or when you wish to stop charging.
5. Unplug the charger from the wall outlet after use.
6. When charging built-in rechargeable batteries, follow the recommended maximum charging times.

3 TECHNICAL SPECIFICATIONS

- Input: 220–240 V, 50/60 Hz, 0,6 A
- Output:
 - USB-A: 5.0 V = 3.0 A, 15.0 W; 9.0 V = 2.0 A, 18.0 W; 12.0 V = 1.5 A, 18.0 W Max
 - USB-C: 5.0 V = 3.0 A, 15.0 W; 9.0 V = 2.22 A, 20.0 W; 12.0 V = 1.67 A, 20.0 W Max
 - PPS: 3.3–5.9 V = 3.0 A, 17.7 W Max; 3.3–11.0 V = 1.8 A, 19.8 W Max
 - USB-C + USB-A: max. 15.0 W
- No-Load Power Consumption: 0,10 W
- Average Active Efficiency:
 - USB-C 20 W: 88,20 %
 - PPS 19,8 W: 88,37 %
- Efficiency at Low Load (10%):
 - USB-C 20 W: 81.36%
 - PPS 19.8 W: 80.32%
- Recommended Operating Temperature: 0–35 °C
- Recycled Materials: PC / Tin

4 WARRANTY

Please contact the store where you purchased the item for any warranty issues.

4.1 WARRANTY CONDITIONS

Dear Customer,
The **ALDI warranty** is a full warranty offering you the following benefits:

WARRANTY PERIOD

2 years from date of purchase.

The warranty does not cover damage caused by:

- Accident or unanticipated events (e.g. lightning, water, fire).
- Improper use or transport.
- Failure to follow the safety and maintenance instructions.
- Other improper treatment or modification of the product.

After the expiration of the warranty period, you may wish to have your product repaired at your own expense.

You will be notified of the repair costs in advance.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state but this warranty is not intended to exceed statutory minimum requirements beyond what is included above.

This warranty does not limit the statutory obligation of the seller arising from any implied warranties.

The period of warranty can only be extended in accordance with applicable law.

Neither the service company nor ALDI will assume any liability for data or settings stored on any returned product.

5 AFTER SALES SUPPORT

If you experience any issues with this product or its performance is not what you had expected, please contact us at Balco. It is likely that we can resolve any problems for you via phone or email.

- Phone: 0800 496 9698 (UK) / 1800 816 994 (Ireland)
- Email: UK-IRE@balcobrands.com
- Website: www.balcobrands.com