



Indoor Remote Controlled Power Points

Model Number: HE214039

INSTRUCTION MANUAL

After Sales Support - Help Desk		
Telephone:	1300 663 907	
Internet:	www.winplus.com.au	













Indoor Remote Controlled Power Points

Warranty Details

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.









Warranty	2
Contents	3
Welcome	4
General Safety Instructions	5
Product Features	6
Parts List / Technical Specifications	7
Installation	8
FAQ'S	10
Repair and Refurbished Goods or Parts Notice	







Welcome

Congratulations on choosing to buy a BAUHN® product. By doing so you now have the assurance and peace of mind that comes with purchasing a product made by one of the leading manufacturers. All products brought to you by BAUHN® are manufactured to the highest standards of performance and safety and, as part of our philosophy of customer service and satisfaction, are backed by our comprehensive 1 Year Warranty. We hope you will enjoy using your purchase for many years to come.









General Safety Instructions

Read this manual thoroughly before first use and keep it in a safe place for future reference, along with the warranty card, purchase receipt and carton. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to. Follow all instructions and take notice of all warnings to reduce the risk of fire or electric shock.

- Do not expose this product to water, rain, moisture or dust. Electronic products of this kind should never be subjected to moisture or extreme temperatures.
- Do not attempt to open the product housing. There are no userserviceable parts inside this product.
- Do not repair the unit yourself. If your device is not functioning correctly, disconnect the product from power, and contact after sales support.
- Supervise young children to ensure they do not play with the product.
- Do not expose to water, dust, moisture, chemicals, oils, or other liquids.
- Do not expose to naked flames or other heat sources.
- Do not drop or subject the device to undue shock.
- Keep device away from magnets at all times.
- Keep away from direct sunlight. Indoor use only.
- Unplug this device during lightning storms or when unused for long periods of time
- Do not operate or control heat producing devices connected to the Power Point Controller unattended.









Product Features

INDOOR POWER POINT CONTROLLER



REMOTE CONTROL



- Up to 30m range
- Control individual outlets, groups of outlets or power all units on/off using the remote control
- · Compact design for easy installation around the home
- Can be used with any 10A device
- · Perfect for the home or office









- 4 x Indoor Remote Controlled Power Points
- Remote Control (Batteries Included)
- Getting Started Guide
- Warranty Card
- Warranty Stickers
- Instruction Manual

Technical Specifications

Voltage: 240V AC, 50Hz

Current: 10A

Max load power: 2400W Remote control frequency: 433.92MHZ

Remote control distance: 433.92\miles 12

Working Temperature: 0~50°C

Remote Control Batteries: 2 x LR44 Button Cells

Warning: Some Computer and AV equipment must be returned to standby mode before power can be turned off to avoid data loss or damage. Always assess the suitability of the appliance you wish to control before using with the Remote Controlled Power Point.







Installation

The Bauhn Indoor Remote Controlled Power Points can be used all around the home or office to turn your appliances on or off with a remote control. Follow the steps below to setup your Indoor Remote Controlled Power Points:

- Unpack contents from the packaging. Check you have all components from the parts list.
- 2. Remove the tab from the rear of the remote control to activate the batteries.
- Connect the device you wish to control to the socket of your power point controller.
- 4. Insert the Power Point Controller into any power outlet.
- Turn on the power outlet. The LED on the Power Point Controller will begin to flash slowly.
- Using the remote control, press the ON button next to the number you wish to assign the Power Point Controller to. Note – The ON button will only need to be pressed once for successful pairing.

Example: Press ON next to the number 1 to assign the Power Point Controller to the number 1 ON/OFF buttons.

- The LED on the Power Point Controller will begin to flash quickly to confirm it has successfully paired to the remote.
- 8. Repeat the above steps to pair the remaining Power Point Controllers.

A. Adding New Controllers to Groups

You can add a new Power Point Controller to a group at any time. The remote will retain all previously paired controllers in the group.

- Connect the Power Point Controller you wish to add to the group to a power outlet.
- Turn on the power outlet. The LED on the Power Point Controller will begin to flash slowly.
- Using the remote control, press the ON button next to the number you wish to add the Power Point Controller to.
- 4. THE LED will flash quickly when successfully paired.







B. Using the Remote Control

Once you have paired your Power Point Controllers to the remote you can control the Power Point Controller from up to 30m away.

- Press the ON button on your remote control which has been paired with the Power Point Controller you wish to use.
- 2. The Power Point Controller LED will light up when ON.
- If you wish to control all the Power Point Controllers paired to the remote control, press the ON or OFF buttons marked "ALL".

Note: Certain materials, walls, floors and wireless interference from other devices may limit the range. If possible, move these devices away from the Power Point unit to improve the transmission distance.

C. To Control Your Power Point Controller Manually

The Bauhn Indoor Power Point Controllers can be switched on or off manually without using the remote control.

 Press the power button marked ON / OFF located on the front of the Power Point Controller to toggle power ON or OFF.

Note: The Power Point Controller LED will be lit when ON.

D. Resetting a Power Point Controller

There are two methods to un-pair or reset the Power Point Controllers.

- Press and hold the ON/OFF button located on the front of the Power Point Controller.
- 2. When the LED begins to flash the Power Point unit has been reset.

Note: This method will reset individual Power Point Controllers. OR

- 1. Press and hold the ALL OFF button on the remote control for 5 seconds.
- When the LED begins to flash the Power Point unit has been reset.

Note: The second method will reset ALL paired Power Point Controllers.







9



Frequently Asked Questions

Question	Answer
My Power Point Controller is not responding	The battery in the remote may be flat. The remote uses 2 x LR44 batteries. Check that you are within the 30m range of the remote control Check that you are pressing the correct button on the remote. If the controller has been paired to number 1, make sure you are pressing the number 1 on/ off buttons.
How long is the range of the remote control?	The remote control has a range of up to 30m line of sight. The range can be affected by the environmental factors such as walls and other electronic devices.
Can I use this outdoors?	No, This product is for indoor use only
Can I pair more than one power point controller per remote control button?	Yes, multiple power point controllers can be set to each button. Plug one or more controllers into an outlet at the same time. When each unit has the LED flashing press the button you wish to assign to on the Remote Control. All units can now be controlled with the same button.











Indoor Remote Controlled Power Points

Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost. We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 663 907 or write to us at:

WINPLUS AUSTRALASIA PO BOX 537 BAYSWATER BUSINESS CENTRE VIC 3153 WINPLUS HELP DESK: 1300 663 907

EMAIL: customercare@winplus.com.au











(



