

BAUHN[®]
EFFORTLESS TECHNOLOGY



Bluetooth Headphones

Model Number: HE314041

INSTRUCTION MANUAL

After Sales Support - Help Desk

Telephone: 1300 663 907
Internet: www.winplus.com.au





BAUHN[®]
EFFORTLESS TECHNOLOGY

Bluetooth Headphones

Warranty Details

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



Contents

Warranty	2
Contents	3
Welcome	4
General Safety Instructions	5
Product Features	6
Parts List	7
Technical Specifications	7
Instructions	8-11
Power On/Off	8
Charging	8
Pairing	8
Pairing Via NFC (Near Field Communication)	9
Audio Playback	10
Phone Calls	10
Connecting via Aux-in	11
Frequently Asked Questions	12
Repair & Refurbished Notice	15



Welcome

Congratulations on choosing to buy a BAUHN® product. By doing so you now have the assurance and peace of mind that comes with purchasing a product made by one of the leading manufacturers. All products brought to you by BAUHN® are manufactured to the highest standards of performance and safety and, as part of our philosophy of customer service and satisfaction, are backed by our comprehensive 1 Year Warranty. We hope you will enjoy using your purchase for many years to come.





General Safety Instructions

Read this manual thoroughly before first use and keep it in a safe place for future reference, along with the warranty card, purchase receipt and carton. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to. Follow all instructions and take notice of all warnings to reduce the risk of fire or electric shock.

- Do not expose this product to water, rain, moisture or dust. Electronic products of this kind should never be subjected to moisture or extreme temperatures.
- Do not attempt to open the product housing. There are no user-serviceable parts inside this product.
- Do not repair the unit yourself. If your device is not functioning correctly, disconnect the product from power, and contact after sales support.
- Supervise young children to ensure they do not play with the product.
- Do not expose to chemicals, oils, or other liquids.
- Do not expose to naked flames or other heat sources.
- Do not drop or subject the device to undue shock.
- Keep device away from magnets at all times.
- Keep away from direct sunlight. Indoor use only.
- Unplug this device during lightning storms or when unused for long periods of time.

Product Features



- Use as wired or wireless headphones
- Modern and lightweight ergonomic design
- Up to 15m transmission range
- Bluetooth 4.0 technology backwards compatible with older Bluetooth devices
- Premium 50mm driver
- Built in microphone for handsfree function
- Play time up to 15 hours per charge
- Standby time up to 250 hours per charge
- Charging time 3-4 hours via included USB charging cable
- Built in rechargeable battery
- High quality memory foam earpads and headband offer increased noise isolation and maximum comfort
- NFC ready for easy pairing with other NFC devices



Parts List

- 1 x Bluetooth Headphones
- 1 x 3.5mm Audio Cable
- 1 x Micro USB cable
- 1 x Instruction Manual
- 1 x Getting Started Guide
- 1 x Warranty Card
- 2 x Warranty Stickers

Technical Specifications

Driver Unit:	50mm
Sensitivity:	110+/-3dB(SPL/mW.1 kHz)
Impedance:	32 Ω \pm 15%
Frequency Range:	20Hz-20KHz
Rated Power:	10mW
Max. Power:	30mW
Bluetooth Version:	4.0 backwards compatible to 2.0+EDR
Transmission Range:	Up to 15m
Standby Time:	Up to 250hrs
Playback / Talk Time:	Up to 15hrs
Battery:	500mAh Lithium Battery
Power Input:	5V, 500mA



Instructions

1. Charging

When fully charged the Bauhn Bluetooth Headphones will last up to 15hrs depending on usage. To charge, simply connect your headphones to a USB outlet on your PC or laptop.

1. Insert included Micro USB plug into Bluetooth Headphones, the charging port is located on the bottom of right ear pad.
2. Connect the USB plug to a spare USB port on your PC or laptop.
3. The LED light will show solid green colour to indicate charging is active.
4. Light will turn off when fully charged.

Tip: When your Bluetooth Headphones are running low on battery. The LED on the bottom of the right ear pad will slowly flash red.

2. Power On/Off

Before first use it is recommended you charge the Bauhn Bluetooth Headphones for at least 1 hour. See section 2 for charging instructions.

To turn on your Bauhn Bluetooth Headphones:

5. Hold down the circle button on the side of the right ear pad for 3 seconds.
6. The headset will state “power on” when you turn on the headphones.
7. The LED on the bottom of the ear pad will quickly flash blue while powered on.

To turn off your Bauhn Bluetooth Headphones:

1. Hold down the circle button on the side of the right ear pad for 3 seconds.
2. The headset will state “power off” when you turn off the headphones.
3. The LED on the bottom of the ear pad will flash red once when powering off.



3. Pairing

The Bauhn Bluetooth Headphones can be paired to a Bluetooth enabled device such as your smartphone or MP3 player.

Pairing for the first time

1. Press and hold the power button for 6 seconds to turn on the Bluetooth Headphones and enter pairing mode.
2. The headset will state “power on” and then “pairing”. The LED will quickly flash blue & red while in pairing mode.
3. Search on your MP3 Player or smartphone for the device “HE314041” and pair as per your MP3 player or smartphone’s instructions.
4. When the Bluetooth Headphones are successfully paired with your device the headphones will state “your headset is connected”
5. The LED on the bottom of the ear pad will slowly double-flash blue when connected via Bluetooth.

Reconnecting to a device

The Bauhn Bluetooth Headphones will automatically reconnect to a device you have previously paired them with when the device is within range.

1. Press and hold the power button for 3 seconds to turn on the Bluetooth Headphones.
2. The headset will state “power on” when you turn on the headphones. The LED on the bottom of the ear pad will quickly flash blue while powered on.
3. The Bluetooth Headphones will begin to automatically search for any previously connected devices within range.
4. When the Bluetooth Headphones are successfully paired with your device the headphones will state “your headset is connected”
5. The LED on the bottom of the ear pad will slowly double-flash blue when connected via Bluetooth.

Note: The headphones can store up to 10 paired devices and will automatically connect to the last paired device when in range.





4. Pairing Via NFC (Near Field Communication)


The Bauhn Bluetooth Headphones also feature NFC (Near Field Communication). This feature lets you quickly and easily pair your Bluetooth Headphones to any NFC enabled Bluetooth device. The below instructions assume NFC is activated on your device. Refer to the manufacturer's instructions if you are unsure how to do this.

1. To pair your Bluetooth Headphones to an NFC enabled device, hold the headphones against device at the bottom of the right ear pad. There is a N icon to indicate the best position. The headphones will automatically turn on.
2. Your NFC enabled device may prompt you to confirm pairing to the Bluetooth Headphones.
3. When the Bluetooth Headphones are successfully paired with your device the headphones will state "your headset is connected"

5. Audio Playback

The Bauhn Bluetooth Headphones features audio playback controls located on the side of the right ear pad. You can control volume and track playback quickly and easily from your Bluetooth Headphones.

- 1 – Volume Up
- 2 – Play / Pause
- 3 – Track Forward
- 4 – Volume Down
- 5 – Track Back



6. Phone Calls

When connected to your Bluetooth enabled phone, you can accept incoming calls through your Bauhn Bluetooth Headphones.





Answering a Call

1. When you receive an incoming call, the ringtone will be heard through your Bluetooth Headphones.
2. Press the circle button located on the right ear pad to answer the call.
3. The built in microphone on the Bluetooth Headphones will pick up your voice as you speak.

Ending a Call

1. When you wish to end a call, press the circle button located on the right ear pad.

Rejecting a call

1. If you receive a call and do not wish to answer it, you can reject the call by holding the circle button located on the right ear pad for 2 seconds.

7. Connecting via Aux-in

The Bauhn Bluetooth Headphones can be directly connected via the aux-in port located on the bottom of the left ear pad.

1. Connect the included 3.5mm audio cable to the aux-in jack located on the left ear pad.
2. Connect the other end of the audio cable to the audio out jack on your audio device

Note: When connected via audio cable, the Bluetooth function and controls are disabled. You cannot control playback using the control when connected via aux-in. The headphones will not be discoverable on Bluetooth.



Frequently Asked Questions

Question	Answer
There is no audio through the headphones when paired to a device	<ul style="list-style-type: none">- Remove any cables connected to the aux-in jack on the headphones.- Turn up the volume on the headphones using the control pad- Turn up the volume on the paired device- Ensure the "HE314041" is selected as the audio output on your device- Try Repairing your device. Only one audio device can be paired at once.
The headphones won't turn on	<ul style="list-style-type: none">- Charge the device for 1 hour using the included Micro USB cable before trying again.
I can't pair to my Bluetooth enabled device	<ul style="list-style-type: none">- Check you are within range of the headphones.- Ensure that Bluetooth is enabled on your phone or MP3 player.- Ensure the headphones are in pairing mode, with LED flashing blue and red rapidly
I can't hear anything when I dial someone/someone dials me	<ul style="list-style-type: none">- Turn up the volume on the headphones using the control pad- Turn up the volume on the paired device- Ensure you have not muted the phone
The NFC function isn't working	<ul style="list-style-type: none">- Check your device features NFC. Refer to the device manufacturers instructions for details.- Check you have activated NFC on your NFC enabled device- Ensure you are holding the NFC enabled device to the N logo located on the bottom of the right ear pad.
Can I use a power adaptor to charge the headphones?	<ul style="list-style-type: none">- The Bauhn Bluetooth Headphones do not include a power adaptor; however, you can charge the device using any USB power Adaptor with 5V, 500mA output. Contact your local electronics store to purchase an adaptor.



Notes:





BAUHN[®]
EFFORTLESS TECHNOLOGY

Bluetooth Headphones

Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost. We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 663 907 or write to us at:

WINPLUS AUSTRALASIA
PO BOX 537
BAYSWATER BUSINESS CENTRE VIC 3153

WINPLUS HELP DESK: 1300 663 907

EMAIL: customercare@winplus.com.au



After Sales Support - Help Desk

Telephone: 1300 663 907
Internet: www.winplus.com.au



BAUHN[®]
EFFORTLESS TECHNOLOGY

