

# BAUHN®

EFFORTLESS TECHNOLOGY

## accessories

### Cordless Headphones

Model Number: HE414066



## GETTING STARTED GUIDE

### 1. Unpack

Unpack the contents of the Bauhn Cordless Headphone pack.



### 2. Power the Base Unit

Insert the plug of the power adaptor to the rear of the base unit. Plug in the power adaptor to a power point and turn on. The LED on the front of the base unit will turn red when connected to power.



Place the headphones on to the base unit. The charge indicator will turn yellow. Charge for 12 hours.



### 3. Turn on Cordless Headphones

When the base unit is powered, switch on the headphones by pressing the power button on the right ear piece.



# BAUHN®

EFFORTLESS TECHNOLOGY

## accessories

## Cordless Headphones

### 4. Connect Audio to Base

Connect the base unit to your audio device via either the RCA cables or 3.5mm audio cable. The LED on the front of the base unit will turn green when it detects audio input.

**Tip: If the green LED does not light up, ensure the volume on your device is set to maximum.**



### 5. Select Channel

Select the channel you wish to use for your Cordless Headphones. The switch used to toggle between channels 1 to 3 is found on the rear of the base unit.

**Note: Change channels if you experience interference or have multiple sets of headphones.**



### 6. Scan for Channel

Press the Scan button on the side of the right ear pad to scan for the channel you selected. You may need to press scan a few times to tune to the correct channel.



Congratulations, your Bauhn Cordless Headphones are ready to use.