

DELTA[®]

HOME SECURITY

DOOR STOP ALARM 2 PACK

Model Number: IT414071B



GETTING STARTED GUIDE

1. Unpack

- Unpack the Delta Door Stop Alarms.

2. Connect the batteries

- Unscrew the bottom plate to open the battery compartment.
- Connect the battery to the battery connector.

3. Switch On

- Turn the switch located on the back of the unit to the "On" position, as shown in diagram 3.

4. Install the Door Stop Alarm

- Find a suitable location for the alarm.

Note: The alarm is best placed close to the doorway to ensure the alarm is activated by opening the door.

5. Switch Off When Not in Use


- Once finished with the Door Stop Alarm, ensure the switch is turned to "Off" using the on/off switch, shown in diagram 3.

Note: If you will not be using the Door Stop Alarm for an extended period, remove the battery before storing.

2a



2b



3



4

