

Professional

STAND MIXER DIE CAST ALUMINIUM 700W











Starting Up:

Ensure you read the instruction manual before attempting operation



Unpack

Place the stand mixer on a level, stable surface. Ensure that the speed control dial is in the OFF position. Plug the power cord into a mains outlet and switch on.



Attach Mixing Tool Attach the required mixing tool by inserting it onto the shaft on the mixer head.



Lift The Mixer Head Rotate the tilt head release lever clockwise and tilt the mixer head upwards until it clicks securely into place.



Place ingredients into the bowl in accordance with your recipe.



Attach Splash Guard Attach the splash guard and easy pour attachment if required.



To start mixing, turn the speed control dial clockwise to the appropriate speed level.



Lock The Bowl

Place the mixing bowl into the base of the mixer and turn it clockwise until it is correctly locked in place.



Lower Mixer Head

Rotate the tilt head release lever clockwise and lower the mixer head into the bowl. Push firmly until it locks securely into place.



When mixing is complete, turn the speed control dial to the OFF position and unplug the unit. Ensure all parts are cleaned after use.



please visit ambiano.com.au or call 1300 663 907

Model Specifications	AP170342
Colour	Green
Voltage	220-240V AC 50/60Hz
Power	700W
Capacity	4L
Weight	6kg
Warranty	3 years