

VISAGE[®]

AP180320
Version 1.1

CORDLESS HAIR CLIPPERS



FEATURES



3-4 HOURS
CORDLESS
OPERATION



22 PIECE
BARBER KIT



BONUS
MIRROR



STAINLESS
STEEL BLADES

USING YOUR HAIR CLIPPERS

To get the best results from your new Hair Clippers, please read the full instruction manual thoroughly and carefully before using. This is a quick start guide only and contains brief instructions




1. Power on the Hair Clipper, then apply 2 drops of oil onto the blades. Leave the Hair Clipper switched ON for a further few seconds to allow the oil spread thoroughly along the length of the blades



2. Select the desired Attachment Comb and place the groove of the Attachment Comb onto the blades' tip at the top of the Hair Clipper



3. Firmly press the rear of the Attachment Comb onto the end of the blade until it 'clicks' and locks into position



4. Power on the Hair Clipper and start cutting

Model:	AP180320
Input voltage:	Adaptor: 100-240VAC, 50/60Hz Clipper: 5VDC
Warranty:	1 Year

FOR MORE INFORMATION
PLEASE EMAIL customer@winplus.com.au
OR CALL 1300 663 907

