

# VISAGE<sup>®</sup>

AP160365  
Version 1.0

## ELECTRIC SHAVER

WITH ROTATING  
HEAD TECHNOLOGY



## FEATURES



WET & DRY  
USE



60 MIN  
OPERATION



STAINLESS  
STEEL  
BLADES



TRIPLE  
SHAVING  
HEADS

# USING YOUR ELECTRIC SHAVER

To get the best results from your new shaver, please read the full instruction manual thoroughly and carefully before using.

This is a quick start guide only and contains brief instructions.



**1.** Fully charge your new shaver before first use. Insert the power adaptor into the charging base. Then insert the other end into a power point and turn ON. Place your shaver into the charging base.



**2.** The unit is fully charged once the power indicator illuminates blue.



**3.** To begin shaving, remove the protective cap & turn the shaver ON by sliding the ON/OFF button upwards.



**4.** With the shaver at a 90° angle to your face, stretch the skin with your free hand. Proceed to shave desired area, using light strokes. Turn shaver OFF when finished.



**5.** Clean after every use. Ensure the shaver is turned OFF and unplugged. Lift each shaving head cover up to clean out the hairs.



**6.** Gently shake out any hair and use the included brush to clean.

Model:	AP160365
Accessories:	Charging Base, Cleaning Brush, Travel Bag
Voltage:	Adaptor: 100-240VAC 50/60Hz   Shaver: 5V DC
Warranty:	1 Year

FOR MORE INFORMATION  
PLEASE EMAIL [customer@winplus.com.au](mailto:customer@winplus.com.au)  
OR CALL 1300 663 907

