

**BAUHN**<sup>®</sup>  
EFFORTLESS TECHNOLOGY

auricle

**NOISE CANCELLING  
HEADPHONES**



**Model Number: HE215028**

# **INSTRUCTION MANUAL**





# Important

**Getting the most out of your Noise Cancelling Headphones:**



## **Read the manual carefully**

It will help you get set up with ease



## **Visit [www.winplus.com.au](http://www.winplus.com.au)**

We've got additional support videos and guides



## **Call After Sales Support - 1300 663 907**

Available Monday - Friday, 8:30am - 6:00pm AEST



## **Email [customercare@winplus.com.au](mailto:customercare@winplus.com.au)**

We're always happy to help

# Warranty Note

**If you experience any issues with this product, or it's performance is not what you had expected, please contact us at Winplus before returning the item to the store.**

**It is likely that we can resolve any problems for you via phone or email.**

**We can be reached on:**

**Phone: 1300 663 907 (Mon - Fri; 8:30am - 6:00pm EST)**

**Email: [customercare@winplus.com.au](mailto:customercare@winplus.com.au)**

**Web: [www.winplus.com.au](http://www.winplus.com.au)**



**BAUHN**<sup>®</sup>  
EFFORTLESS TECHNOLOGY

## NOISE CANCELLING HEADPHONES

# Warranty Details

---

REGISTER YOUR PURCHASE AT [www.aldi.com.au/en/about-aldi/product-registration/](http://www.aldi.com.au/en/about-aldi/product-registration/) TO KEEP UP-TO-DATE WITH IMPORTANT PRODUCT INFORMATION



---

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

---

#### AFTER SALES SUPPORT

  1300 663 907

 [customercare@winplus.com.au](mailto:customercare@winplus.com.au)

MODEL: HE215028 PRODUCT CODE: 49430 11/2017



# Safety Instructions

Read this manual thoroughly before first use and keep it in a safe place for future reference, along with the warranty card, purchase receipt and carton. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to. Follow all instructions and take notice of all warnings to reduce the risk of fire or electric shock.

- Do not expose this product to water, rain, moisture or dust. Electronic products of this kind should never be subjected to moisture or extreme temperatures
- Do not attempt to open the product housing. There are no user-serviceable parts inside this product
- Do not repair the unit yourself. If your device is not functioning correctly, disconnect the product from power, and contact after sales support
- Supervise young children to ensure they do not play with the product
- Do not expose device to chemicals, oils, or other liquids
- Do not expose device to naked flames or other heat sources
- Do not drop or subject the device to undue shock
- Keep device away from magnets at all times
- Keep away from direct sunlight. Indoor use only
- Unplug this device during lightning storms or when unused for long periods of time

## After Sales Support



1300 663 907



customercare@winplus.com.au

**Model Number** HE215028

# Contents

<b>Warranty Details</b>	<b>4</b>
<b>Safety Instructions</b>	<b>5</b>
<b>Parts List</b>	<b>7</b>
<b>Technical Specifications</b>	<b>7</b>
<b>Product Features</b>	<b>7</b>
<b>Product Overview</b>	<b>8</b>
<b>Instructions</b>	<b>9</b>
Charging	<b>9</b>
Placing The Headphones On Your Head	<b>9</b>
For Audio And Noise Cancelling	<b>9</b>
For Noise Cancelling Only	<b>9</b>
Storing Your Headphones	<b>10</b>
Using The Airline Adaptor	<b>10</b>
<b>FAQs</b>	<b>11</b>
<b>Disposal</b>	<b>12</b>
<b>Maintain and Storage</b>	<b>12</b>
<b>Repair and Refurbished Goods or Parts Notice</b>	<b>14</b>

## After Sales Support



1300 663 907



customercare@winplus.com.au

**Model Number** HE215028

# Parts List

1x Bauhn Noise Cancelling Headphones  
1x 3.5mm Audio Cable  
1x Micro USB Cable  
1x Travel Case

1x Airline Adaptor  
1x Instruction Manual  
1x Getting Started Guide  
1x Warranty Card




## Technical Specifications

Driver Unit:	40mm
Sensitivity:	+/-5dB
Frequency Range:	20Hz-20KHz
Rated Power:	10mW
Max. Power:	30mW
Battery:	550mAh Lithium Battery
Power Input:	DC 5V, 500mA

## Product Features

- Modern and lightweight ergonomic design
- Standard PU ear pads and headband
- 40mm driver high quality
- Swivel and fold ear pads
- Built-in rechargeable battery
- High quality memory foam ear pads and headband offer increased noise reduction and maximum comfort

### After Sales Support

 1300 663 907

 [customercare@winplus.com.au](mailto:customercare@winplus.com.au)

**Model Number** HE215028


# Product Overview




- 1. Noise Cancelling On/Off button
- 2. Audio Jack

- 3. Status Indicator
- 4. Charging Jack

## After Sales Support

 1300 663 907

 [customercare@winplus.com.au](mailto:customercare@winplus.com.au)

Model Number HE215028



# Instructions

## Charging

When fully charged, the Bauhn Noise Cancelling Headphones will last up to 15hrs depending on usage. To charge, simply connect your headphones to a USB outlet on your PC or laptop using the Micro USB cable provided.

1. Insert included Micro USB plug into Noise Cancelling Headphones. The charging port is located on the bottom of right ear pad.
2. Connect the USB plug to a spare USB port on your PC or laptop.
3. Charge for 2 hours for a full charge.

**NOTE:** LED light turns off when fully charged.

## Placing The Headphones On Your Head

When placing the headphones on your head, make note of the R (Right) and L (Left) markings on the inside of the ear cups. Adjust the ear pads to fit comfortably over your ears and ensure that the headband is gently resting on the top of your head.

## For Audio And Noise Cancelling

### 1. Connect the 3.5mm audio jack

Insert the 3.5mm audio cable into the bottom of the left ear cup. Insert the other end of the cable into your phone or MP3 Player.

### 2. Start audio playback

Start audio playback on your phone or MP3 player. Refer to your device's instruction manual for details on audio playback.

### 3. Turning on/off noise cancelling

Use the ON/OFF switch on the back of the right ear cup to activate and deactivate the noise cancelling feature. Slide the switch upwards to activate. Once activated, the LED on the bottom of the ear cup will turn blue.

## For Noise Cancelling Only

You can also use your headphones for noise cancelling only.

Use the ON/OFF switch on the back of the right ear cup to activate and deactivate the noise cancelling feature. Slide the switch upwards to activate. Once activated, the LED on the bottom of the ear cup will turn blue.

## After Sales Support

 1300 663 907

 [customercare@winplus.com.au](mailto:customercare@winplus.com.au)

Model Number HE215028

# Instructions

## Storing Your Headphones

### 1. Swivel and Fold

Swivel and fold ear cups to allow for easy and convenient storage.

**NOTE:** Ear cups are only able to rotate in one direction. Incorrect forced rotation can damage the headphones.

### 2. Store In Travel Case

Place the headphones into the travel case as shown below. Secure with the elastic strap.



**NOTE:** To maximise battery life, ensure battery is charged before storing.



## Using The Airline Adaptor

Audio outputs can vary between different airlines. Generally a dual or single 3.5mm audio jack is present.

For single 3.5mm audio jacks, plug your audio cable directly from your headphones into the jack.

For dual 3.5mm audio jacks, plug your audio cable into your headphones and insert the other end into the airline adaptor. Plug the airline adaptor into the dual 3.5mm audio jack.

**NOTE:** Audio quality will vary between airlines.

## After Sales Support

 1300 663 907

 [customercare@winplus.com.au](mailto:customercare@winplus.com.au)

Model Number HE215028

# FAQs

Question	Solution
There is no audio through the headphones when plugged in to a device	<ul style="list-style-type: none"><li>• Turn up the volume on the device that it is plugged in to.</li></ul>
Noise Cancelling won't turn on	<ul style="list-style-type: none"><li>• Make sure the power switch is turned to ON and the LED status indicator is a solid blue.</li><li>• Charge the device for 2 hours using the included Micro USB cable before trying again.</li></ul>
Will the headphones still work without power?	<ul style="list-style-type: none"><li>• Yes, the Noise Cancelling Headphones will work like standard headphones if the battery has run out and the noise cancelling function is switch off.</li></ul> <p><b>NOTE:</b> <i>The noise cancelling function will not work without power</i></p>
Can I use a power adaptor to charge the headphones?	<ul style="list-style-type: none"><li>• The Bauhn Noise Cancelling Headphones do not include a power adaptor; however, you can charge the device using any USB power Adaptor with 5V, 500mA output. Contact your local electronics store to purchase an adaptor.</li></ul>

## After Sales Support

 1300 663 907

 [customercare@winplus.com.au](mailto:customercare@winplus.com.au)

Model Number HE215028

# Disposal

At the end of its working life, do not throw this product out with your household rubbish. Electrical and electronic products contain substances that can have a detrimental effect on the environment and human health if disposed of inappropriately. Observe any local regulations regarding the disposal of electrical consumer goods and dispose of it appropriately for recycling. Contact your local authorities for advice on recycling facilities in your area.

Observe and local regulations regarding the disposal of waste products. Contact your local authorities for advise on recycling facilities in your area.

Please keep the original packaging carton and materials in a safe place. It will help to prevent any damage if the product needs to be transported in the future. In the event it is to be disposed of, please recycle all packaging material where possible.

If you require another copy of this instruction manual, please contact [customercare@winplus.com.au](mailto:customercare@winplus.com.au) to obtain an electronic copy.

# Maintain and Storage

The headphones do not require scheduled cleaning. Should cleaning be necessary, simply wipe the outside surface with a dry soft cloth. Be sure the earcup ports are kept clear, and that no moisture is allowed to get inside the earcup.

Always store your headphones in protective case, store in a clean dry environment and avoid storage in extreme heat or cold.

## After Sales Support



1300 663 907



[customercare@winplus.com.au](mailto:customercare@winplus.com.au)

**Model Number** HE215028





**BAUHN**<sup>®</sup>  
EFFORTLESS TECHNOLOGY

**NOISE CANCELLING HEADPHONES**

# Repair and Refurbished Goods or Parts Notice

---

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost.

**We recommend you save this data elsewhere prior to sending the product for repair.**

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

**Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.**

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 663 907 or write to us at:

Winplus Australasia



PO Box 537 Bayswater Business Centre, Victoria, Australia

1300 663 907 - Hours: Mon-Fri 8:30am - 6:00pm AEST

customercare@winplus.com.au

---

**AFTER SALES SUPPORT**

  1300 663 907

 [customercare@winplus.com.au](mailto:customercare@winplus.com.au)

MODEL: HE215028 PRODUCT CODE: 49430 11/2017

**1**

**YEAR WARRANTY**



**BAUHN®**