SMALL ROOFTOP TENT Instruction Manual



Model: OU200233 Version 1.1



Warranty Note

Small Rooftop Tent

Getting the most out of your Small Rooftop Tent:



Read the entire manual It will help you set up with ease

Visit www.balcobrands.com We have additional support guides

Call After Sales Support -Or email customercare@balcobrands.com - we're always happy to help

Your Small Rooftop Tent comes with a 1 year manufacturer's warranty

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

If you experience any issues with this product or its performance is not what you had expected, please contact our friendly customer service team

It is likely that we can resolve problems for you via phone or email

We can be reached on:

Phone: 1300 663 907 (Mon - Fri; 8:30am - 6:00pm AEST) Email: customercare@balcobrands.com Web: www.balcobrands.com

After Sales Support



customercare@balcobrands.com Model number: OU200233 www.balcobrands.com 11/2020

Contents

Small Rooftop Tent

Warnings & Notes Maintenance	_4
Maintenance	5
Pack Contents	6
Specifications	7
Operation	8
	-10
Folding Away	_12

After Sales Support

11/2020

Warnings & Notes

Small Rooftop Tent

- 1. Keep the small rooftop tent windows open when folding.
- Make sure nothing is left in the small rooftop tent before folding, for example sleeping bags, pillows, etc.
- 3. Do not put anything on the top of the small rooftop tent when the tent is on the car whether it is in use or not.
- Please double check that the nuts that lock the bedframe together with the roof racks are tightened after installation and before driving.
- 5. Do not do strenuous exercise inside the tent.
- Ensure the cover is closed and the buckle lock is securely fastened before driving! Maximum driving speed 110KM per hour.
- 7. The water-resistant cover must be on and secured while driving.
- 8. Before using the ladder, make sure that all rungs have been locked.
- 9. Check all parts are in good working condition before using. Do not use damaged, worn-out, chemically etched ladder.
- Set the ladder on firm ground. Do not let it stand on one leg. Do not set it on unsteady ground which as gangue, ice or snow in it without any anti-skid device.
- 11. Before climbing the ladder, please make sure the crosspieces are locked. Please do not reach out your body far away. Otherwise you will lose your balance. Face the ladder while climbing up and down, hold firmly the ladder with both hands. Distribute your body weight on the middles of the rungs. Do not climb on a single side. Do not jump from the ladder.
- **12.** Do not pull out the top cross piece unless the ladder is fully extended, or it may fall.
- 13. Do not press the contract switch when in use to avoid injury to person.
- **14.** Make sure the ladder is clean. Keep it from grease, dirt, snow, paint, and chemicals.
- 15. Do not conduct any temporary maintenance on the ladder to damaged parts.
- **16.** The bedframe and the ladder are all electric conductors, keep away from any live parts.
- **17.** There must be an angle of 75 degrees between the ground and the ladder when in use.
- **18.** To provide children with protection, do not leave the ladder standalone without any attention.

After Sales Support

Warnings & Notes

- 19. When contracting, grasp the ladder rod by one hand, and press the left and right switches of the lowest crosspieces. Do collapse the ladder down-top sequentially and slowly. Caution to avoid hand injuries!
- To extend the ladder, you need to pull out rungs bottom-up sequentially and lock each rung carefully.
- 21. Before extending the ladder, make sure the ground is flat. To reduce the height, please collapse the ladder firstly, and then extend it again to the height you want.
- 22. Do not use the tent and ladder in strong wind weather.
- The design of the ladder only permits one person to use and max loading is 150kg.

Maintenance

1. Use a wet cloth to clean the tent - allow to dry fully before folding.

Pack Contents

Small Rooftop Tent

- 1. 1 x Small rooftop tent grey with orange
- 2. 1 x Telescopic ladder
- 3. 1 x Mattress
- 4. 1 x Tooling bag including:
 - a. 4 x U-shaped fixing plate
 - b. 8 x M8x50 bolt hexagon head
 - c. 8 x Plain washer
 - d. 8 x Spring washer
 - e. 8 x M8x30 bolt, hexagon head
 - f. 8 x Plain washer
 - g. 8 x Spring washer
 - h. 1 x Ratchet wrench 13mm
 - i. 1 x Hexagon bar wrench (allen key) 6mm
 - j. 10 x M8 self locking nut
 - k. 4 x Insert with spring ball
 - I. 4 x M8x12 bolt, hexagon sockets
 - m. 4 x Spring washer
 - n. 4 x 30 x 30 plastic caps
 - o. 4 × Fillet
- 5. 1 x Manual

After Sales Support



Specifications

Small Rooftop Tent

- Closed size: 130 x 105 x 32cm .
- Open size: 221 x 130 x 102cm ٠
- Weight: 51kg .
- Aluminium frame .
- Aluminium telescopic ladder
- Mattress: 7cm thick .
- Fabric: .
 - Fly: 210D silver coated oxford fabric (waterproof: 3000mm & UV 50+)
 - Inner body : 190gsm polycotton (waterproof : 2000mm) .
 - Outer cover: 610G PVC with net fabric .



After Sales Support

8 1300 663 907

customercare@balcobrands.com Model number: OU200233 www.balcobrands.com

over

Small Rooftop Tent

- At least 2 people are needed to install a Balco Small Rooftop Tent.
- The small rooftop tent should be installed so the opening is over either passenger . or driver side doors. Do not install to open over the boot of the car.
- 1. Ensure that the roof racks have more then 3cm between the rack and the top of the car.

Note: You will need a set of suitable roof racks and have them install on the car roof before you install the tent. You will need to check with the manufacture of the roof racks that they will be suitable for use with a rooftop tent.

2. Remove the small rooftop tent from the box and place on a clean surface. You will need to have access to the bottom of the tent. If you can see the two connecting tubes this is the bottom, if not carefully turn the tent

Note: We recommend that two people turn the tent over, this will make it easier and help prevent any damage to the tent.

- 3. According to the direction and size of the roof rack. loosen the screws, and adjust the direction and distance of the two-connecting tubes on the bottom of the tent, then tighten the screws.
- 4. Place the tent on the roof of the car and adjust the tent to an appropriate position on the car roof

Note: Make sure that the boot door can be opened without hitting the tent.





After Sales Support

8 1300 663 907

www.balcobrands.com

customercare@balcobrands.com Model number: 0U200233

Small Rooftop Tent

5. Once you are happy with the position, slide the M8 x 50 bolts to the appropriate position from the end of the connecting tube. There needs to be one bolt on each side of the rack

Note: When the distance between the roof rack and the car roof is less than 4cm the short bolts (M8 x30) will need to be used instead of the longer M8x50 bolts.



6. The bolts pass through the hole of the u - shape fixing plate, flat washer then spring washer, then tighten the M8 self-locking nut using a ratchet wrench. This needs to be done on four corners, respectively.



Insert the plastic cap (30x30cm) into the 7. end of the connecting tubes.



After Sales Support

3 1300 663 907

customercare@balcobrands.com Model number: 0U200233 www.balcobrands.com

Small Rooftop Tent

- **Unfolding 1.** Take off the cover.
- 2. Hold firmly on the lowest rung of the ladder and then pull the ladder towards yourself and away from the car. This will start to open the tent







www.balcobrands.com

customercare@balcobrands.com Model number: OU200233

Small Rooftop Tent

- Once you have the ladder out, you will need to extent the ladder completely. Secure the front of the small rooftop tent by sliding the pole into the connector on each corner at the front. There is one on each side.
- You can adjust the height using the rungs at the top. All rungs need to be fully extended and locked into place before use. When in use the ladder should be at an 75° angle.





5. Once inside the tent connect the roof poles to each end of the small rooftop tent.


Small Rooftop Tent

Folding Away

- Make sure there is nothing left inside before you 1. start folding it away.
- 2. Open all of the windows and leave them open before you start to fold away.
- 3. Release the roof poles at the front and inside the tent.
- 4. Press and hold the button on the bottom of the ladder. As you fold the ladder over it will fold the small rooftop tent.
- 5. Cover the small rooftop tent with the waterproof over after folded, make sure you hook the cover around the bedframe, and it is secure.







After Sales Support



www.balcobrands.com

customercare@balcobrands.com Model number: OU200233



After Sales Support

Ph. 1300 663 907 customercare@balcobands.com