



Wireless Charger

Quick start guide

GENERAL SAFETY INSTRUCTIONS

- Do not disassemble or throw into fire or water, to avoid damage
- Do not use Wireless Charger in severely hot, humid or corrosive environments, to avoid circuit damage and leakage
- Do not place too close to magnetic strips or chip cards (ID card, credit cards, etc.) to avoid magnetic failure
- Please keep a distance of at least 30cm between implantable medical devices (pacemakers, implantable cochlear, etc.) and the Wireless Charger, to avoid potential interference with the medical device
- Ensure children do not play with the Wireless Charger. This is not a toy
- Do not use damaged power cords, plugs or loose electrical sockets
- Only use original cable and reputable third-party chargers
- Do not clean the Wireless Charger with harmful chemicals or detergents
- Misuse, dropping or excessive force may cause damage to the charging pad
- Do not touch the device, power cords, plugs, or the electric socket with wet hands or other wet body parts
- Do not place other materials, like metal objects, magnets, and magnetic stripe cards, between the mobile device and the wireless charger pad

NOTE:

- *Not all phones are wireless charging compatible, check your phone specifications to ensure your phone is compatible*
- *Some phone cases may not be compatible with wireless charging*
- *When the mobile device is not placed on the charging area accurately, your mobile device may not charge properly*

PRODUCT OVERVIEW

1. Vertical Charging Area
2. Horizontal Charging Area
3. LED Indicator Light
4. USB-C Power Input

Box contents

- 1 x Wireless Charger
- 1 x USB-C Power Cable
- 1 x User Guide
- 1 x Warranty Certificate



SPECIFICATIONS

- Coils: 2pcs
- Wireless Output: 15W (9V-1.67A)
- Size: 96.5 x 68.5 x 103mm
- Material: Recycled ABS
- Accessory: 100cm USB-A to USB-C in recycled TPE

GETTING STARTED

How to use your Wireless Charger

1. Plug the USC-C end of the supplied charging cable into the USB-C input port on the Wireless Charger
2. Plug the large connector into the USB port on a computer or a 5V DC USB adapter (not included) and plug into a wall socket
3. The LED indicator light will illuminate red when power is connected to the device
4. The Wireless Charger is ready for your mobile device
5. Place your device vertically or horizontally on the Wireless Charger ensuring the screen is face up. The LED indicator light will illuminate blue to signify the phone is charging

The LED indicator light will flash blue and red when an object is obstructing the charging coils. Remove the phone from the charger and ensure no object is between the phone and the charger before proceeding.

AFTER SALES SUPPORT

Phone: 1300 663 907 (Mon - Fri 8:30am - 6:00pm)

Email: customercare@balcobrands.com