

BAUHN®



True Wireless Earbuds

User guide



HE210334-E
06/22

SAFETY WARNINGS

- Only use attachments/accessories specified by the manufacturer
 - To avoid accidental ingestion, keep the earbuds away from children and pets
 - The earbuds contain a lithium-ion battery, and may be hazardous if swallowed
 - If ingested, seek immediate medical attention
 - When not in use, store the earbuds in the charging case with the lid closed, and keep out of reach of children and pets
 - Do NOT use the earbuds at a high volume for any extended period
 - To avoid hearing damage, use your earbuds at a comfortable, moderate volume level
 - Turn the volume down on your device before placing the earbuds in/on your ears, then turn the volume up gradually until you reach a comfortable listening level
 - Use caution and follow applicable laws regarding mobile phone and headphone use if using the earbuds for phone calls while driving
 - Some jurisdictions impose specific limitations, such as single earpiece configuration, on the use of such products while driving
 - DON'T use the earbuds for any other purpose while driving
 - Focus on your safety and that of others if you use the earbuds while engaging in any activity requiring your attention, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad and follow applicable laws regarding headphone use, etc.
 - Remove the earbuds or adjust your volume to ensure you can hear surrounding sounds, including alarms and warning signals
 - Do NOT allow children to use the earbuds
 - Do NOT submerge or expose the earbuds for extended period to water, or wear while participating in water sports, e.g., swimming, water-skiing, surfing, etc
 - To reduce the risk of injury, close supervision is necessary when the charging case is used near children
 - Do not expose charging case to water, rain, liquids or snow
 - Do not use the charging case in excess of its output rating
 - Do not use a charging case that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury to persons
 - Do not disassemble the charging case. Incorrect reassembly may result in risk of fire or injury to persons
 - Do not open, crush, or expose a charging case to fire, or excessive temperature. Exposure to fire or temperature above 45°C may cause explosion
 - Have servicing performed by a qualified repair person using only identical replacement parts
 - Do NOT make unauthorized alterations to this product
 - Use this product only with an agency approved power supply which meets local regulatory requirements (e.g., RCM)
 - Wipe off sweat from the earbuds and the charging case before charging
 - This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device
 - Excessive sound pressure from earphones and headphone can cause hearing loss
 - Attention should be drawn to the environmental aspects of battery disposal
 - Use only with charger base provided with the earbuds
 - Use of apparatus in moderate climates
 - This product shall not be connected to power supply source exceeding PS1. 5V d.c. 15W.
- CAUTION: Risk of explosion:**
- If the battery is replaced by an incorrect type.
 - If the battery is subjected to high or low extreme temperatures that a battery can be subjected to during use, storage or transportation.
 - If the battery is subjected to low air pressure at high altitude.
 - Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types).
 - Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
 - Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
 - A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

PRODUCT OVERVIEW

1. Earbuds charging point
2. Microphone
3. LED indicator light
4. Smart control area
5. Multi function button
6. Charging case charging port

NOTE: Product rating label is on bottom of charging case

In the box

- 1 x True Wireless Earbuds
- 1 x Earbud Charging Case
- 1 x USB C Charging Cable
- 1 x User Guide
- 1 x Warranty Certificate

SPECIFICATIONS

- Bluetooth version: V5.1
- Music playtime: 3-4 hours
- Earbud battery: 40mAh
- Wireless distance: 10m
- Charging case battery: 300mAh
- Charge time: 1.5 hours
- Charging voltage: DC 5V

NOTE: Product rating label is on bottom of charging case

GETTING STARTED

Charging case

1. Connect the USB C end of the supplied USB C charging cable into the charging case charging port
2. Connect the USB end of the charging cable into PC or AC/DC wall adaptor (not provided)

When the case is plugged in the case LED indicator lights will illuminate blue to signify charging.

Charging earbuds

The earbuds will start charging when put back into the charging case. The earbuds LED indicator light will light up red to signify charging.

Certain mobile devices will also display an on-screen headset battery indicator while the headphones are connected

USAGE

Turning on/off

Turning on

- Open the charging case, the earbuds will power on automatically. Take both earbuds out from the charging case, they will turn on and connect with each other automatically

Turning off

- Put the earbuds back into the charging case and close completely, they will turn off automatically

Pairing

1. Take both earbuds out from the charging case, they will power on and connect with each other automatically
2. Enable Bluetooth on your device and select "HE210344-E" from the list to connect
3. Your device will show if it is connected successfully

Smart control area

You can control a variety of different functions on your mobile device using the smart control area on your earbuds

Play/Pause Music	Tap on the smart control area on either earbud
Next Track	Triple tap on the smart control area on the right earbud
Previous Track	Triple tap on the smart control area on the left earbud
Volume Up	Double tap the smart control area on the right earbud
Volume Down	Double tap the smart control area on the left earbud
Answer/End Call	Tap the smart control area
Reject Incoming Call	Press and hold the smart control area for 2 seconds when a call is incoming
Activate Voice Assistant	Press and hold the smart control area on either earbud for two seconds

AFTER SALES SUPPORT

Phone: 1300 663 907 (Mon - Fri 8:30am - 6:00pm)

Email: customercare@balcobrands.com