


WIRELESS SPORTS EARBUDS

USER GUIDE



SAFETY WARNINGS

- Only use attachments/accessories specified by the manufacturer.
- To avoid accidental ingestion, keep the earbuds away from children and pets.
- The earbuds contain a lithium-ion battery, and may be hazardous if swallowed.
- If ingested, seek immediate medical attention.
- When not in use, store the earbuds in the charging case with the lid closed, and keep out of reach of children and pets.
- Do NOT use the earbuds at a high volume for any extended period.
- To avoid hearing damage, use your earbuds at a comfortable, moderate volume level.
- Turn the volume down on your device before placing the earbuds in/on your ears, then turn the volume up gradually until you reach a comfortable listening level.
- Use caution and follow applicable laws regarding mobile phone and headphone use if using the earbuds for phone calls while driving.
- Some jurisdictions impose specific limitations, such as single earpiece configuration, on the use of such products while driving.
- DON'T use the earbuds for any other purpose while driving.
- Focus on your safety and that of others if you use the earbuds while engaging in any activity requiring your attention, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad and follow applicable laws regarding headphone use, etc.
- Remove the earbuds or adjust your volume to ensure you can hear surrounding sounds, including alarms and warning signals.
- Do NOT allow children to use the earbuds. Contains small parts which may be a choking hazard.
- Do NOT submerge or expose the earbuds for extended period to water, or wear while participating in water sports, e.g., swimming, water-skiing, surfing, etc.
- To reduce the risk of injury, close supervision is necessary when the charging case is used near children.
- Do not expose charging case to water, rain, liquids or snow.
- Do not use the charging case in excess of its output rating.
- Do not use a charging case that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury to persons.
- Do not disassemble the charging case. Incorrect reassembly may result in risk of fire or injury to persons.
- Do not open, crush, or expose a charging case to fire, or excessive temperature. Exposure to fire or temperature above 45°C may cause explosion.
- Have servicing performed by a qualified repair person using only identical replacement parts.
- Do NOT make unauthorized alterations to this product.
- Use this product only with an agency approved power supply which meets local regulatory requirements (e.g., CE).
- Wipe off sweat from the earbuds and the charging case before charging.
- This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.
- Excessive sound pressure from earphones and headphone can cause hearing loss.
- Attention should be drawn to the environmental aspects of battery disposal.
- Use only with charger base provided with the earbuds.
- Use of apparatus in moderate climates.
- This product shall not be connected to power supply source exceeding PS1. 5V d.c. 15W.


- CAUTION: Risk of explosion:**
- If the battery is subjected to high or low extreme temperatures that a battery can be subjected to during use, storage or transportation.
 - If the battery is subjected to low air pressure at high altitude.
 - Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
 - Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
 - A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

- High sound pressure
- Hearing damage risk
- Do not listen at high volume levels for long periods

IN THE BOX

1. Wireless sports earbuds
2. Charging case
3. 3 X Pairs of silicone tips (S, M, L)
4. USB charging cable
5. User guide*

*Not pictured




FUNCTIONS

- a. Touch control area
- b. LED indicator light
- c. Charging case indicator lights
- d. Charging case charging port
- e. Microphone (internal)*

Note: Product rating label is located on the bottom of charging case

*Not pictured



CHARGING

Charging Case

1. Connect the USB C end of the supplied USB C charging cable into the charging case charging port.
2. Connect the USB end of the charging cable into PC or AC/DC wall adaptor (not provided).

NOTE: Use a 5V DC USB output. Maximum current: 500mA.

While charging, the four white LED lights indicate battery level:

- 4 lights solid – 100% charged
- 3 solid, 1 flashing – 75% charged
- 2 solid, 1 flashing – 50% charged
- 1 solid, 1 flashing – 25% charged
- 1 flashing – Less than 25% charged

Earbuds

The earbuds will start charging when put back into the charging case. A red LED will be displayed if the earbuds are charging, once fully charged this light will turn off.

TURNING ON/OFF

Turning On

The earbuds will automatically turn on when removed from the charging case. To manually power the earbuds on, long tap the control areas for 5 seconds and you will receive a prompt.

Turning Off

The earbuds will automatically turn off when placed in the charging case. To manually power the earbuds off, long tap the control areas for 5 seconds and you will receive a prompt.

PAIRING

1. Place both earbuds into the charging case to activate the earbuds.
2. Take both earbuds out from the charging case, they will power on and connect with each other automatically.
3. The LED will flicker Red/Blue to indicate that the earbuds are now in pairing mode.
4. Enable Bluetooth on your device and select “CE220799” from the list to connect.
5. Your device will show if it is connected successfully.

NOTE:

- The earbuds will automatically connect to your last previously connected device. To connect to a new device first disconnect the earbuds from the currently paired device.
- The earbuds will switch to off mode after 3 minutes if Bluetooth is not paired.

AFTER SALES SUPPORT

AU 1300 663 907

customer@baldobrand.com

MODEL: CE220799
SELLABLE ID: 735862

W1

1

YEAR

WARRANTY

TOUCH CONTROL AREA

You can control various functions using the control areas located on either the left or right side of the earbuds.

Function	Operation
Play/Pause Music	Short tap either the left or right earbud
Next Track	Long tap right earphone 2 seconds
Previous Track	Long tap left earphone 2 seconds
Answer Call	With a call incoming short tap either the left or right earbud
End Call	During a call short tap either the left or right earbud
Reject Incoming Call	With a call incoming long tap either the left or right earbud
Activate Voice Assistant	Double tap either left earphone or right earphone to turn on voice assistant

TECH SPECS

Model Number:	CE220799
Driver Size:	8mm
Impedance:	16Ω
Bluetooth Version:	5.4
Bluetooth Range:	Up to 10 metres
Earbuds Playback Time:	Up to 5 hours (50% volume)
Total Playback Time (with charging case):	Up to 15 hours (50% volume)
Power Input:	DC 5 V / 500 mA
Water Resistance (Earbuds Only):	IPX5*
Charging Case Battery:	3.7V, 400mAh, 1.48Wh
Earbuds Batteries:	3.7V, 40mAh, 0.148Wh

**An IPX5 rating means a device is protected against water jets projected from any direction. This level of protection is suitable for devices exposed to rain or splashes, but not for submersion in water.*

WARRANTY

1. Warranty Certificate

REGISTER YOUR PURCHASE AT www.aldi.com.au/en/about-aldi/product-registration TO KEEP UP-TO-DATE WITH IMPORTANT PRODUCT INFORMATION

Congratulations! You have made an excellent choice of this quality product. Our commitment to quality also includes our service. Should you, contrary to expectations, experience defects due to manufacturing faults, ALDI will provide you with a warranty against defects as follows:

The product is guaranteed to be free from defects in workmanship and parts for a period of **12 months** (dependant on product) from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion.

The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

2. Proof of Purchase

This warranty is valid for the original purchase and is not transferable. Please keep your purchase docket, tax invoice or receipt as the best proof of purchase, and as proof of date on which the purchase was made.

3. Extent of Warranty

This warranty is limited to defects in workmanship or parts. All defective products or parts will be repaired or replaced. This warranty does not cover batteries or any other consumable items.

4. Normal Wear and Tear

This warranty does not cover normal wear and tear to the products or parts.

5. Exclusions

This warranty does not cover:

- Any defects caused by an accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorised modification, loss of parts, tampering or attempted repair by a person not authorised by the distributor.
- Any product that has not been installed, operated or maintained in accordance with the manufacturer's operating instructions provided with the product.
- Any product that has been used for purposes other than domestic use.
- Any damage caused by improper power input or improper cable connection.

6. To Make a Claim

This warranty against defects is provided by:

ALDI Stores, Locked Bag 56, St Marys Delivery Centre, NSW 2760, Phone (02) 9675 9000.

If a defect in the goods appears within **12 months** (the identified period on the packaging), you are entitled to claim a warranty, please contact or send all warranty claims to:

Balco Brands Pty Ltd. PO Box 537 Bayswater Business Centre, Victoria, Australia
Phone: 1300 663 907 (Mon - Fri; 8:30am - 6:00pm AEST)
Email: customercare@balcobrands.com

When making a return, please ensure the product is properly packaged so as to ensure that no damage occurs to the product during transit. Please provide the original or a copy of the proof of purchase. Also please make sure you have included an explanation of the problem. Please note that the costs of making a warranty claim, including any return postage, will be covered by the supplier identified above. Please note upon receiving your warranty claim, the supplier will send, via the post or email, a repair and refurbished goods or parts notice. Please provide your email address and advise the supplier, if you wish to obtain a repair and refurbished goods or parts notice via email.

7. Warranty Details

The product is guaranteed to be free from defects in workmanship and parts for a period of **12 months** from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

8. Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost.

We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. We can be reached on:

Phone: 1300 663 907 (Mon - Fri; 8:30am - 6:00pm AEST)
Email: customercare@balcobrands.com
Web: www.balcobrands.com

ALDI guarantees that our exclusive brand products are developed to our stringent quality specifications. If you are not entirely satisfied with this product, please return it to the nearest ALDI store within 60 days from the date of purchase, for a full refund or replacement.

Bauhn® is a registered trademark of Hands (IP) Holdings Pty Ltd.

DISTRIBUTED BY

ALDI STORES
1 SARGENTS ROAD,
MINCHINBURY NSW 2770
WWW.ALDI.COM.AU

Made in China