


WIRELESS CLIP-ON EARBUDS

USER GUIDE

BAUHN®



SAFETY WARNINGS

- Only use attachments/accessories specified by the manufacturer.
- To avoid accidental ingestion, keep the earbuds away from children and pets.
- The earbuds contain a lithium-ion battery, and may be hazardous if swallowed.
- If ingested, seek immediate medical attention.
- When not in use, store the earbuds in the charging case with the lid closed, and keep out of reach of children and pets.
- Do NOT use the earbuds at a high volume for any extended period.
- To avoid hearing damage, use your earbuds at a comfortable, moderate volume level.
- Turn the volume down on your device before placing the earbuds in/on your ears, then turn the volume up gradually until you reach a comfortable listening level.
- Use caution and follow applicable laws regarding mobile phone and headphone use if using the earbuds for phone calls while driving.
- Some jurisdictions impose specific limitations, such as single earpiece configuration, on the use of such products while driving.
- DON'T use the earbuds for any other purpose while driving.
- Focus on your safety and that of others if you use the earbuds while engaging in any activity requiring your attention, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad and follow applicable laws regarding headphone use, etc.
- Remove the earbuds or adjust your volume to ensure you can hear surrounding sounds, including alarms and warning signals.
- Do NOT allow children to use the earbuds. Contains small parts which may be a choking hazard.
- Do NOT submerge or expose the earbuds for extended period to water, or wear while participating in water sports, e.g., swimming, water-skiing, surfing, etc.
- To reduce the risk of injury, close supervision is necessary when the charging case is used near children.
- Do not expose charging case to water, rain, liquids or snow.
- Do not use the charging case in excess of its output rating.
- Do not use a charging case that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury to persons.
- Do not disassemble the charging case. Incorrect reassembly may result in risk of fire or injury to persons.
- Do not open, crush, or expose a charging case to fire, or excessive temperature. Exposure to fire or temperature above 45°C may cause explosion.
- Have servicing performed by a qualified repair person using only identical replacement parts.
- Do NOT make unauthorized alterations to this product.
- Use this product only with an agency approved power supply which meets local regulatory requirements (e.g., CE).
- Wipe off sweat from the earbuds and the charging case before charging.
- This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.
- Excessive sound pressure from earphones and headphone can cause hearing loss.
- Attention should be drawn to the environmental aspects of battery disposal.
- Use only with charger base provided with the earbuds.
- Use of apparatus in moderate climates.
- This product shall not be connected to power supply source exceeding PS1. 5V d.c. 15W.

CAUTION: Risk of explosion:

- If the battery is subjected to high or low extreme temperatures that a battery can be subjected to during use, storage or transportation.
- If the battery is subjected to low air pressure at high altitude.
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.




- High sound pressure
- Hearing damage risk
- Do not listen at high volume levels for long periods

IN THE BOX

1. Wireless clip-on earbuds
2. Charging case
3. USB charging cable
4. User guide*



*Not pictured




FUNCTIONS

- a. Touch control area
- b. Microphone & status indicator
- c. Charging connectors
- d. LED status light
- e. USB-C charging port

Note: Product rating label is located on the back of charging case



Front of case



Back of case

CHARGING

Charging the Case

- Connect the USB-C charging cable to the USB-C port on the charging case.
- Connect the other end of the cable to a USB power source or power adapter.

Battery Level	Charging Case Indicator Status
< 33%	Flashes white
33% - 66%	Solid white
> 66%	Solid green
100%	Light off

Charging the Earbuds

- Place both earbuds into the charging case.
- Charging will begin automatically.

Charging Case Battery Level	Charging Case Indicator Status	Earbuds Indicator Status
< 33%	White indicator flashes for 3 seconds, then turns off	Solid red
33% - 66%	White indicator remains on for 3 seconds, then turns off	Solid red
> 66%	Green indicator remains on for 3 seconds, then turns off	Solid red
100%	Light off	Light off

TURNING ON/OFF

Auto

- **Auto Power On:** Open the charging case and take out the earbuds. They will automatically turn on.
- **Auto Power Off:** If the earbuds are not connected to any device within 3 minutes, they will automatically turn off.

Manual

- **Manual Power On:** Long tap the Touch control areas for 3 seconds to turn on the earbuds.
- **Manual Power Off:** Long tap the Touch control areas for 5 seconds or place the earbuds back into the charging case to turn them off.

PAIRING

1. **Prepare the Earbuds:** After turning on, place the left and right earbuds close together. The main earbud will flash red and white alternately, indicating it is ready to pair.
2. **Connect on Your Device:** Open the Bluetooth settings on your device and select "CE220884".
3. **Pairing Complete:** Once the connection is successful, the indicator light will turn off.



V1.1

AFTER SALES SUPPORT

AU 1300 663 907

customer@baldobrand.com

MODEL: CE220884
SELLABLE ID: 735862

08/2026

1

YEAR

WARRANTY

TOUCH CONTROL AREA

You can control various functions using the control areas located on the back of either the left or right earbuds.

Function	Left Earbud	Right Earbud
Play Music	 x2 Double tap	 x2 Double tap
Pause Music	 x2 Double tap	 x2 Double tap
Volume +	—	 x1 Single tap
Volume -	 x1 Single tap	—
Previous Song	 2s  Hold for 2 seconds	—
Next Song	—	 2s  Hold for 2 seconds
Answer Call	 x1 Single tap	 x1 Single tap
Hang Up	 x2 Double tap	 x2 Double tap
Reject Call	 2s  Hold for 2 seconds	 2s  Hold for 2 seconds
Voice Assistant	 x3 Triple tap	—
Game Mode / Music Mode	—	 x3 Triple tap
Reset	 x5 Tap 5 times	 x5 Tap 5 times



TECH SPECS

Model Number: CE220884
Driver Size: 12 mm
Bluetooth Version: 5.4
Bluetooth Range: Up to 10 metres
Earbuds Playback Time: Up to 6 hours (50% volume)
Total Playback Time (with charging case): Up to 28 hours (50% Volume)
Power Input: DC 5 V / 500 mA
Water Resistance (Earbuds Only): IPX5*
Charging Case Battery: 3.7V, 500mAh, 1.85Wh
Earbuds Battery: 3.7V, 50mAh, 0.19Wh

**An IPX5 rating means a device is protected against water jets projected from any direction. This level of protection is suitable for devices exposed to rain or splashes, but not for submersion in water.*

WARRANTY

1. Warranty Certificate

REGISTER YOUR PURCHASE AT www.aldi.com.au/en/about-aldi/product-registration/TO KEEP UP-TO-DATE WITH IMPORTANT PRODUCT INFORMATION
Congratulations! You have made an excellent choice of this quality product. Our commitment to quality also includes our service. Should you, contrary to expectations, experience defects due to manufacturing faults, ALDI will provide you with a warranty against defects as follows:
The product is guaranteed to be free from defects in workmanship and parts for a period of **12 months** (dependant on product) from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion.
The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

2. Proof of Purchase

This warranty is valid for the original purchase and is not transferable. Please keep your purchase docket, tax invoice or receipt as the best proof of purchase, and as proof of date on which the purchase was made.

3. Extent of Warranty

This warranty is limited to defects in workmanship or parts. All defective products or parts will be repaired or replaced. This warranty does not cover batteries or any other consumable items.

4. Normal Wear and Tear

This warranty does not cover normal wear and tear to the products or parts.

5. Exclusions

This warranty does not cover:

- Any defects caused by an accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorised modification, loss of parts, tampering or attempted repair by a person not authorised by the distributor.
- Any product that has not been installed, operated or maintained in accordance with the manufacturer's operating instructions provided with the product.
- Any product that has been used for purposes other than domestic use.
- Any damage caused by improper power input or improper cable connection.

6. To Make a Claim

This warranty against defects is provided by:
ALDI Stores, Locked Bag 56, St Marys Delivery Centre, NSW 2760, Phone (02) 9675 9000.
If a defect in the goods appears within **12 months** (the identified period on the packaging), you are entitled to claim a warranty, please contact or send all warranty claims to:
Balco Brands Pty Ltd. PO Box 537 Bayswater Business Centre, Victoria, Australia
Phone: 1300 663 907 (Mon - Fri; 8:30am - 6:00pm AEST)
Email: customercare@balcobrands.com

When making a return, please ensure the product is properly packaged so as to ensure that no damage occurs to the product during transit. Please provide the original or a copy of the proof of purchase. Also please make sure you have included an explanation of the problem. Please note that the costs of making a warranty claim, including any return postage, will be covered by the supplier identified above. Please note upon receiving your warranty claim, the supplier will send, via the post or email, a repair and refurbished goods or parts notice. Please provide your email address and advise the supplier, if you wish to obtain a repair and refurbished goods or parts notice via email.

7. Warranty Details

The product is guaranteed to be free from defects in workmanship and parts for a period of **12 months** from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

8. Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.
Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost.
We recommend you save this data elsewhere prior to sending the product for repair.
You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.
Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.
If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. We can be reached on:
Phone: 1300 663 907 (Mon - Fri; 8:30am - 6:00pm AEST)
Email: customercare@balcobrands.com
Web: www.balcobrands.com

ALDI guarantees that our exclusive brand products are developed to our stringent quality specifications. If you are not entirely satisfied with this product, please return it to the nearest ALDI store within 60 days from the date of purchase, for a full refund or replacement.

Bauhn® is a registered trademark of Hands (IP) Holdings Pty Ltd.

DISTRIBUTED BY

ALDI STORES
1 SARGENTS ROAD,
MINCHINBURY NSW 2770
WWW.ALDI.COM.AU

Made in China