

BAUHN®

PREMIUM NOISE CANCELLING HEADPHONES WITH BLUETOOTH®



MODEL NUMBER: HE170751

INSTRUCTION MANUAL

Version 1.0



Important

Getting the most out of your headphones:



Read the manual carefully

It will help you set up with ease



Visit www.winplus.com.au

We have additional support videos and guides



Call After Sales Support - 1300 663 907

Available Monday - Friday, 8:30am - 6:00pm AEST



Email customercare@winplus.com.au

We're always happy to help

Warranty Note

If you experience any issues with this product or its performance is not what you had expected, please contact us at Winplus before returning the item to the store.

It is likely that we can resolve any problems for you via phone or email.

We can be reached on:

Phone: 1300 663 907 (Mon - Fri: 8:30am - 6:00pm EST)

Email: customercare@winplus.com.au

Web: www.winplus.com.au



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth Sig, Inc. and any use of such marks by BAUHN is under license. Other trademarks and trade names are those of their respective owners.



BAUHN®

PREMIUM NOISE CANCELLING HEADPHONES WITH BLUETOOTH®

Warranty Details

REGISTER YOUR PURCHASE AT www.aldi.com.au/en/about-aldi/product-registration/ TO KEEP UP-TO-DATE WITH IMPORTANT PRODUCT INFORMATION

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

AFTER SALES SUPPORT

1300 663 907

customercare@winplus.com.au

MODEL: HE170751 PRODUCT CODE: 60369 11/2019



Safety Instructions

Hearing Safety

Headphones can deliver sounds at loud volumes and high-pitched tones. Exposure to such sounds can result in permanent hearing loss or damage. The volume level may vary based on conditions such as the phone you are using, its reception and volume settings and the environment. Please read the safety guidelines below prior to using these headphones.

1. Prior to using this product follow these steps:
 - a. Before putting on the headphones, turn the volume control to its lowest level
 - b. Put the headphones on
 - c. Slowly adjust the volume control to a comfortable level
2. During the use of this product:
 - a. Keep the volume at the lowest level possible and avoid using the headphones in noisy environments where you may be inclined to turn up the volume
 - b. If increased volume is necessary, adjust the volume control slowly
 - c. If you experience discomfort or ringing in your ears, immediately discontinue using the headphones and consult a physician

With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

CAUTION

Using the headphones while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions. Check your local laws. Use caution while using your headphones when you are engaging in any activity that requires your full attention. While engaging in any such activity, removing the headphones from your ear area or turning off your headphones will keep you from being distracted, to avoid accident or injury.

- If you have a pacemaker or other electrical medical devices, you should consult your physician before using the product
- This package contains small parts that may be hazardous to children. Always store the product out of reach of children. The bags themselves or the many small parts they contain may cause choking if ingested
- Never try to dismantle the product yourself, or push objects of any kind into the product, as this may cause short circuits which could result in a fire or electric shock
- None of the components can be replaced or repaired by users. Only authorized dealers or service centres may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer
- Avoid exposing your product to rain, moisture, or other liquids
- If the product overheats, has been dropped or damaged or has been dropped in a liquid, discontinue use
- Dispose of the product according to local standards and regulations
- When you disconnect the power cord or any enhancement, grasp and pull the plug, not the cord. Never use a charger that is damaged
- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type
- Battery shall not be exposed to excessive heat such as sunshine, fire or the like
- Attention should be drawn to the environmental aspects of battery disposal
- The use of apparatus in moderate climates

This product has been tested according to AS/NZS 4268 and AS/NZS CISPR32

After Sales Support

1300 663 907

customercare@winplus.com.au

Model Number HE170751

Contents

Warranty Details	4
Safety Instructions	5
Parts List	7
Technical Specifications	7
Product Features	7
Product Overview	8
Instructions	9
Charging the battery	9
Power On/Off	9
Pairing to a mobile device	9
Search for the headphones	9
Listening to your device	10
Turning ON/OFF noise cancellation	10
Phone calls	10
Answering a call	10
Ending a call	10
Rejecting a call	10
Using the audio cable	10
FAQs	11
Disposal	12
Maintain and Storage	12
Repair and Refurbished Goods or Parts Notice	14

Parts List

1 x Premium Noise Cancelling Headphones with Bluetooth	1 x Carry Case
1 x Micro USB Charging Cable	1 x Instruction Manual
1 x 3.5mm AUX Cable	1 x Getting Started Guide
1 x Airline Adaptor	1 x Warranty Card



Technical Specifications

Driver Unit:	40mm
Impedance:	32Ω
Frequency Range:	20Hz-20KHz
Bluetooth Version:	4.0
Rated Power:	10mW
Max. Power:	20mW
Transmission Range:	Up to 20 metres
Playback time:	up to 15 hours
Battery:	550mAh Lithium Battery
Power Input:	DC 5V, 500mA

Product Features

- Superior audio performance engineered to deliver exceptional sound quality
- Listen longer, up to 15 hours per charge
- Intuitive controls and helpful voice prompts

After Sales Support

 1300 663 907  customercare@winplus.com.au

Model Number HE170751

After Sales Support

 1300 663 907  customercare@winplus.com.au

Model Number HE170751

Product Overview



1. **Noise Cancelling Switch**
2. **3.5mm Jack**
3. **+ Button** - Tap to go to next track, hold to raise volume
4. **► Button** - Tap to play/pause or answer/end calls, hold to enter pairing mode
5. **- Button** - Tap to go to previous track, hold to lower volume
6. **Power Switch**
7. **Micro USB Charging Port**

After Sales Support

1300 663 907 [customer care@winplus.com.au](mailto:customercare@winplus.com.au)

Model Number HE170751

Instructions

Charging the battery

Before first use, it is recommended you charge your Bauhn Premium Headphones for a minimum of 1 hour.

1. Insert the small end of the included Micro USB cable into the Micro USB connector on the headphone's right ear pad
2. Connect the other end of the charging cable to a USB port on your PC or laptop
3. The LED light will show a solid red colour to indicate charging is active
4. The light will turn green when fully charged




NOTE:

- Charge only with 5V DC 500mA input
- Use only the original Micro USB charging cable to avoid any damage
- When the LED flashes blue, the battery is low, charge the headphones

Power On/Off

To Turn On the Bauhn Premium Headphones:

1. The power switch is located below the volume control, press the power switch upwards
2. The headphones will state "power on" when the headphones are turned on



To Turn Off the Bauhn Premium Headphones:


1. Press the power switch downwards. The power switch is located below the volume control
2. The headphones will state "power off" when the headphones are turned off

Pairing to a mobile device

Activate headphone pairing mode:

1. While the Bauhn Premium Headphones are on, press and hold the ► button for 5 seconds
2. The Bauhn Premium Headphones will then enter pairing mode and the LEDs on the bottom will flash red and blue
3. The Bauhn Premium Headphones will then give an audio cue of "pairing"

NOTE: On first use the headphones will automatically enter pairing mode.



Search for the headphones

1. Enter the Bluetooth settings on the device you would like to connect to
2. Search for the device "Bauhn Headphones" and pair as per your MP3 player or smartphone's instruction manual
3. When the Bauhn Premium Headphones are successfully paired with your device, the headphones will give an audio cue of "your device is connected"



After Sales Support

1300 663 907 [customer care@winplus.com.au](mailto:customercare@winplus.com.au)

Model Number HE170751

Instructions

Listening to your device

Once you have successfully paired to a device, open a music app on your device to start listening to music. While listening to music you can play, pause, track forward, track backward and change the volume using the headphone controls/device controls.

NOTE: Refer to Page 8 for the headphone controls.

Turning ON/OFF noise cancellation

Use the noise cancelling switch on the left ear cup to activate and deactivate the noise cancelling feature. Slide the switch upwards to activate. Once activated, the LED on the bottom of the left ear cup will turn blue.



Phone calls

When connected to your Bluetooth enabled phone, you can accept incoming calls through your Bauhn Premium Headphones.

Answering a call

When you receive an incoming call, the ringtone will be heard through your Bauhn Premium Headphones. Press the ► button while the phone is ringing to answer an incoming call.

Ending a call

When you wish to end a call, press the ► button located on the right ear pad.

Rejecting a call

If you receive a call and do not wish to answer it, you can reject the call by holding down the ► button located on the right ear pad.

Using the audio cable

The included audio cable can be used to connect to a non-wireless device or for listening to music when the headphone batteries have been depleted.

1. Connect the included 3.5mm audio cable to the aux-in jack located on the left ear pad
2. Connect the other end of the audio cable to the audio jack



NOTE: When connected via audio cable, the Bluetooth function and controls are disabled. You cannot control playback using the headphone controls when connected via aux-in. The headphones will not be discoverable on Bluetooth.

FAQs

Question	Solution
Poor sound quality	<ul style="list-style-type: none"> • Move the device closer to the headphones, and away from any interference. • Try pairing to another mobile device.
Headphones do not connect to mobile device	<ul style="list-style-type: none"> • Ensure that you are within range of the headphones. • On your device turn OFF Bluetooth and turn it on again. Then try pairing the device again. • Try pairing to another mobile device. • Ensure your device has Bluetooth capabilities.
I can't hear anything when I dial someone/someone dials me	<ul style="list-style-type: none"> • Turn up the volume on the headphones using the control pad. • Turn up the volume on the paired device. • Ensure you have not muted the phone.
Headphones do not turn on	<ul style="list-style-type: none"> • Charge your device for 1 hour using the included Micro USB charging cable. • Make sure the power switch has been turned ON.
Having trouble pairing the Bauhn Premium Headphones to my laptop/PC	<ul style="list-style-type: none"> • Ensure your laptop/PC has Bluetooth capabilities. • Refer to your laptop/PC manual for pairing instructions.
No sound	<ul style="list-style-type: none"> • Make sure the headphones are ON and battery is charged. • Ensure that the volume is turned up on the headphones and your mobile device (or music app). • Try pairing to another device. • Try using a different music App.
No sound when connected via audio cable	<ul style="list-style-type: none"> • Make sure the connected device is ON and playing. • Make sure the 3.5mm plug is fully inserted into the headphones connector, and fully inserted into the source. • Ensure that the volume is turned up on your mobile device (or music app).
Noise cancelling wont turn on	<ul style="list-style-type: none"> • Make sure the headphone power switch is turned ON and the LED status indicator is solid blue • Check that the noise cancelling switch is also turned ON and the LED status indicator is solid blue • Charge your device for 1 hour using the included Micro USB cable

After Sales Support

1300 663 907

customercare@winplus.com.au

Model Number HE170751

After Sales Support

1300 663 907

customercare@winplus.com.au

Model Number HE170751

Disposal

At the end of its working life, do not throw this product out with your household rubbish. Electrical and electronic products contain substances that can have a detrimental effect on the environment and human health if disposed of inappropriately. Observe any local regulations regarding the disposal of electrical consumer goods and dispose of it appropriately for recycling. Contact your local authorities for advice on recycling facilities in your area.

Please keep the original packaging carton and materials in a safe place. It will help to prevent any damage if the product needs to be transported in the future. In the event it is to be disposed of, please recycle all packaging material where possible.

If you require another copy of this instruction manual, please contact customercare@winplus.com.au to obtain an electronic copy.

Maintain and Storage

The headphones do not require scheduled cleaning. Should cleaning be necessary, simply wipe the outside surface with a dry soft cloth. Be sure the earcup ports are kept clear, and that no moisture is allowed to get inside the earcup.

Always store your headphones in its protective case, store in a clean dry environment and avoid storage in extreme heat or cold.

Battery Care

- Make sure that your headphones are switched OFF after use.
- Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.
- Before storing the headphones for long periods of time, be sure to fully charge the battery.
- When the battery is low and flashing red you must charge the headphones.
- If the battery is completely discharged, the headphones cannot be turned on immediately when the charger is connected. Allow a depleted battery to charge for a few minutes before turning on the headphones.
- Always try to keep the battery between 15°C and 30°C. A product with a hot or cold battery may not work temporarily, even when the battery is fully charged.





BAUHN®

PREMIUM NOISE CANCELLING HEADPHONES WITH BLUETOOTH®

Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost.

We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 663 907 or write to us at:



Winplus Australasia

PO Box 537 Bayswater Business Centre, Victoria, Australia

1300 663 907 - Hours: Mon-Fri 8:30am - 6:00pm AEST

customercare@winplus.com.au

AFTER SALES SUPPORT

  1300 663 907

 customercare@winplus.com.au

MODEL: HE170751 PRODUCT CODE: 60369 11/2019



